


# Service manual

R32 Monobloc heat pump



# Content

<b>1.</b>	<b>General Information</b>	<b>3</b>
1.1.	General presentation	3
1.2.	Product line	3
1.3.	External appearance	3
<b>2.</b>	<b>Product overview</b>	<b>4</b>
2.1.	Layout of components	4
2.2.	Piping diagram	8
2.3.	Refrigerant flow diagram	10
2.4.	Exploded views	12
<b>3.</b>	<b>Electronic parts</b>	<b>16</b>
3.1.	Layout of the electronic parts	16
3.2.	Presentation of PCB	18
3.3.	Wiring diagram	23
3.4.	Switch setting and function information	25
<b>4.</b>	<b>Control logic</b>	<b>28</b>
4.1.	General control logic	28
4.2.	Start up control	30
4.3.	Normal operation control	31
4.4.	Stop control	33
4.5.	Standby control	33
4.6.	Protection control	34
4.7.	Special control	37
4.8.	Function table of sensors	40
<b>5.</b>	<b>Troubleshooting</b>	<b>42</b>
5.1.	Error code	42
5.2.	Running parameter checking	44
5.3.	Troubleshooting	50
<b>6.</b>	<b>Components maintaining</b>	<b>97</b>
6.1.	Tooling presentation	97
6.2.	Maintaining step	98
<b>7.</b>	<b>WUI operation</b>	<b>117</b>
7.1.	Presentation	117
7.2.	User operation	121
7.3.	Configuration	130
7.4.	Parameter and statue checking	135
7.5.	Error code of WUI	137

Annex I	138
<b>Resistance table of sensors</b>	138
Annex II	142
<b>Version information</b>	142

# 1. General Information

## 1.1.General presentation

This series of monobloc is using the R32 refrigerant and reached the high efficiency with A+++. It is designed for heating and cooling applications in new and existing individual homes and small businesses.

The unit is compatible with low to medium temperature emitters: underfloor heating, fan coil units, radiators, domestic hot water, etc.

The unit is operating with wide temperature range and leaving water temperature range:

Operation in cooling mode with an outdoor temperature of -5°C ~50°C, leaving water temperature of 5°C ~25°C.

Operation in heating mode with an outdoor temperature of -25°C ~43°C, leaving water temperature of 25°C ~62°C.

## 1.2.Product line

The capacity of the monobloc includes 4kW-16kW as the below table:

Table 1-2-1


Capacity (Kw)	4	6	8	10	12	14	16
Power supply	220-240V/1N/50Hz				220-240V/1N/50Hz 380-415V/1N/50Hz		

Note: The capacity from 4-10kW only has 1-phase; while the 12-16kW has both 1- phase and 3-phase.

## 1.3.External appearance

The external appearance of the unit:

Table 1-3-1


Capacity	4-10kW	12-16kW
Pictures		

## 2. Product overview


### 2.1. Layout of components

4-10kW


Picture 2-1-1: front view with E-box




Picture 2-1 with E-box



Picture 2-1-3: front view without E-box




Picture 2-1-4: rear view without E-box




**12-16kW**


Picture 2-1-5: front view with E-box



Picture 2-1-6: top view




Picture 2-1-7: front view without E-box




## 2.2.Piping diagram

### Piping diagram of 4-10kW



Picture 2-2-1

### Piping diagram of 12-16kW



Picture 2-2-2

### Acronym

- T1: Leaving water sensor after electrical heater;
- Tw-i: Entering water sensor
- Tw-o: Leaving water sensor after BPHE
- T2B: Refrigerant temp. of BPHE
- T3: Refrigerant temperature of condenser

T4: Outdoor ambient temperature  
TP: Discharged temperature  
T7: PCB refrigerant cooling pipe temperature  
BPHE: Brazed plate heat exchanger  
EXV: Electronic expansion valve  
SV: Solenoid valve

### **Key components**


1. Accumulator:  
Stores liquid refrigerant and oil to protect compressor from liquid hammering.
2. Electronic expansion valve (EXV):  
Controls refrigerant flow and reduces refrigerant pressure.
3. Four-way valve:  
Controls refrigerant flow direction. Closed in cooling mode and open in heating mode. When closed, the air side heat exchanger functions as a condenser and water side heat exchanger functions as an evaporator; when open, the air side heat exchanger functions as an evaporator and water side heat exchanger function as a condenser.
4. High-pressure and low-pressure switches:  
Regulate refrigerant system pressure. When refrigerant system pressure rises above the upper limit or falls below the lower limit, the high-pressure switch or low-pressure switch turns off, stopping the compressor.
5. Air purge valve:  
Automatically removes air from the water circuit.
6. Safety valve:  
Prevents excessive water pressure by opening at 6 bar and discharging water from the water circuit.
7. Buffer tank:  
Balances water system pressure.
8. Water flow switch:  
Detects water flow rate to protect compressor and water pump in the event of insufficient water flow.
9. Backup heater:  
Provides additional heating capacity when the heating capacity of the heat pump is insufficient due to very low outdoor temperature. Also protects the external water piping from freezing.
10. Water pump:  
Circulates water in the water circuit.

### 2.3.Refrigerant flow diagram

Here are the refrigerant flow diagrams during unit's operation (12-16kW, double fan for example):


- : High temperature refrigerant
- : Low temperature refrigerant
- : Spray liquid cooling pipe
- : Flow direction

**Cooling mode and defrost operation:**





Picture 2-3-1


**Heating mode and domestic hot water operation:**



Picture 2-3-2

**2.4.Exploded views**  
**Exploded view of 4-10kW**







Picture 2-4-1

Table 2-4-1

No.	Name	QTY	No.	Name	QTY
1	Left plate	1	27	ODU PCB	1
2	Holder component of motor	1	28	IDU PCB	1
3	Top cover	1	29	Terminal	2
4	Cover of reactor box	1	30	Pressing button of cable	2
5	Reactor box	1	31	Relay	1
6	Septum of refrigerant system	1	32	Suction pipe components	1
7	Septum of water system	1	33	Inlet pipe of accumulator	1
8	Rear plate	1	34	4-way valve component	1
9	Hander 1	1	35	Discharged pipe component	1
10	Hander 2	1	36	EXV component	1
11	Seat plate of cable hole	1	37	PCB refrigerant cool pipe	1
12	Holder plate of electrical heater	1	38	Condenser	1
13	Column	1	39	Fan blade	1
14	Right-rear plate	1	40	Compressor	1
15	Holder plate of IDU PCB	1	41	Brazed plate heat exchanger	1
16	Base-pan of hydraulic kit	1	42	Buffer vessel	1
17	Holder plate of ODU PCB	1	43	Safety valve	1
18	Right-front plate	1	44	Water flow switch	1
19	Base-pan of refrigerant system	1	45	Water outlet pipe of unit	1
20	Medium-front plate	1	46	Water outlet pipe of BPHE	1
21	Front plate	1	47	Air purge valve	1
22	Holder seat of unit	1	48	Electrical heater component	1
23	Grill	1	49	Water inlet pipe of BPHE	1
24	Reactor	1	50	Water inlet pipe of unit	1
25	DC motor	1	51	Water pump	1
26	Accumulator	1			

Exploded view of 12-16kW



Picture 2-4-2


Table 2-4-2

No.	Name	QTY	No.	Name	QTY
1	Top cover component	1	21	Base-pan holder	1
2.1	Motor holder	1	22	4-way valve component	1
2.2	Connected plate of motor holder	1	23	EXV component	1
2.3	DC Motor	2	24	Suction pipe	1
2.4	Fan blade	2	25	Condenser outlet pipe component	1
3	Median septum	1	26	Condenser component	1
4	ODU PCB seat component	1	27	Accumulator	1
5	Front column	1	28	Compressor	1
6	Right septum	1	29.1	Electrical heater component	1
7	Seat plate of BPHE	1	29.2	Air purge valve	1
8	IDU PCB seat component	1	30	Water connected pipe	1
9	Grill	2	31	Water flow switch	1
10	Front panel	1	32.1	Expansion vessel	1
11	Column	1	32.2	Softy connected pipe	1
12	Mid-front panel	1	33.1	Safety valve	1
13	Service panel	1	33.2	Connector	1
14	Mid-rear panel	1	33.3	Drainage pipe	1
15	Rear column	1	34	Water pipe of pump	1
16	Right panel	1	35	Pump	1
17	Big hander	1	36	Connected pipe between BPHE & Pump	1
18	Valve seat	1	37	BPHE	1
19	Seat plate of cable cross-hole	1	38	Water inlet pipe of BPHE	1
20.1	Base-pan of hydraulic kit	1			
20.2	Base-pan of refrigerant system	1			

### 3. Electronic parts


#### 3.1. Layout of the electronic parts

4-10kW




Picture

12-16kW



Pictur

### 3.2.Presentation of PCB Presentation of IDU PCB




Picture 3-2-1

The function of the CB unit is shown in the following table:

No.	Function	Notes
1	Power supply	Not applicable
2	Microcontroller	Not applicable
3	Memory	Not applicable
4	Ports of sensors	
5	IDU combination port	Reserved
6	ODU combination port	Reserved
7	Modbus connection port	T5: DHW sensor; T1B: External heat source LWT sensor; Tsolar: Reserved; Tw2: Bi-zone sensor, reserved Tbt2: EWT sensor of the buffer vessel Tbt1: LWT sensor of the buffer vessel T1: LWT sensor of the unit Tw-out: LWT sensor of the BPHE Tw-in: EWT sensor of the BPHE T2B: Refrigerant temperature sensor of BPHE inlet pipe T2: Refrigerant temperature sensor of BPHE outlet pipe (Reserved) T4: Indoor ambient temperature sensor (Reserved)
8	Standard dry controlled port	Cool/heat; ON/OFF; Home/away
9	Water flow switch port	
10	Remote on/off port	Room card function

11	Solar heat source control signal port	Reserved
12	Thermostat controlled port	220V control for ON/OFF (can not work together with WUI)
13	Inv. Pump power port	
14	Customized input	Dry contact
15	Bi-zone valve	Reserved
16	Customized input	Dry contact
17	Electrical heater ports for main water loop	
18	Electrical heater ports for DHW tank	
19	3-way valve connection ports	SV3-1: External heat source 3-way valve SV3-2: Reserved SV3-3: DHW 3-way valve
20	Additional pump connection port	P-p: Bi-zone water pump P-o: Main water loop water pump P-m: External heat source water pump
21	Anti-frozen crank heater	For expansion vessel
22	Unit state signal ports	220V outputs R1-R2: Running signal DF1-DF2: Defrost signal AL1-AL2: Alarm signal
23	External heat source control signal port	220V output AHS1-ASH2
24	IDU 220V power supply port	
25	DIP switches	
26	Checking buttons	
27	LED display	

**Presentation of ODU PCB (Single phase)**



Picture 3-2-2

The port of the ODU PCB is definite

w table:


Table 3-2-2

No.	Defi		Note
1	220Vpower supply poi		
2	SV2 valve connection	Spray liqui	g solenoid valve
3	SV3 valve connection	Reserved	
4	Compressor crank heat	ection port	
5	Base-pan heater connection port		
6	4-way valve coil connection port		
7	LP&HP switches port	Low pressure and high pressure	
8	High pressure sensor connection port	Reserved	
9	T7 sensor connection port	Refrigerant cooling pipe sensor if IPM	
10	Sensors group connection port	T3: ODU condenser pipe temp. sensor T4: ODU ambient sensor TP: Discharged temp. sensor	
11	EXV connection port		
12	Fan driven board power connection port	Only for 12-16kw, double fan unit	
13	IDU PCB communication port		
14	Fan driven board communication board	Only for 12-16kw, double fan unit	
15	DC motor connection port	Only for 4-10kw, single fan unit	
16	Compressor connection port		
17	Reactor connection ports		

**Presentation of ODU PCB (Three phase)**

(reserved)

**Presentation of fan driven PCB (Only for 12-16kw, single phase)**



Connection ports of motor

Communication port of ODU PCB


Power supply from ODU PCB



# ELECTRICAL WIRING DIAGRAM


80205700061

V.0



Number	Point checklist	Content
1	Frequency or quantity of error in indoor units	
2	Outdoor unit capacity	
3	Total capacity demand of indoor units	
4	Running mode (1: 2-cooling mode, 3: heating mode, 4: boost/heating)	
5	Actual running capacity of outdoor unit	
6	Fan motor speed (3)	
7	Two-in heat exchanger water inlet temperature	
8	Two-out heat exchanger water outlet temperature	
9	TI indoor box outlet temperature	
10	TI condenser temperature	
11	TI 4-artificial temperature	
12	TI discharge temperature	
13	TI 2-artificial temperature	
14	TI 1-artificial temperature	
15	TI 3-artificial temperature	
16	TI 5-artificial temperature	
17	TI 6-artificial temperature	
18	TI 7-artificial temperature	
19	TI 8-artificial temperature	
20	TI 9-artificial temperature	
21	TI 10-artificial temperature	
22	TI 11-artificial temperature	
23	TI 12-artificial temperature	
24	TI 13-artificial temperature	
25	TI 14-artificial temperature	
26	TI 15-artificial temperature	
27	TI 16-artificial temperature	
28	TI 17-artificial temperature	
29	TI 18-artificial temperature	
30	TI 19-artificial temperature	
31	TI 20-artificial temperature	
32	TI 21-artificial temperature	
33	TI 22-artificial temperature	
34	TI 23-artificial temperature	
35	TI 24-artificial temperature	
36	TI 25-artificial temperature	
37	TI 26-artificial temperature	
38	TI 27-artificial temperature	
39	TI 28-artificial temperature	
40	TI 29-artificial temperature	
41	TI 30-artificial temperature	
42	TI 31-artificial temperature	
43	TI 32-artificial temperature	
44	TI 33-artificial temperature	
45	TI 34-artificial temperature	
46	TI 35-artificial temperature	
47	TI 36-artificial temperature	
48	TI 37-artificial temperature	
49	TI 38-artificial temperature	
50	TI 39-artificial temperature	
51	TI 40-artificial temperature	
52	TI 41-artificial temperature	
53	TI 42-artificial temperature	
54	TI 43-artificial temperature	
55	TI 44-artificial temperature	
56	TI 45-artificial temperature	
57	TI 46-artificial temperature	
58	TI 47-artificial temperature	
59	TI 48-artificial temperature	
60	TI 49-artificial temperature	
61	TI 50-artificial temperature	
62	TI 51-artificial temperature	
63	TI 52-artificial temperature	
64	TI 53-artificial temperature	
65	TI 54-artificial temperature	
66	TI 55-artificial temperature	
67	TI 56-artificial temperature	
68	TI 57-artificial temperature	
69	TI 58-artificial temperature	
70	TI 59-artificial temperature	
71	TI 60-artificial temperature	
72	TI 61-artificial temperature	
73	TI 62-artificial temperature	
74	TI 63-artificial temperature	
75	TI 64-artificial temperature	
76	TI 65-artificial temperature	
77	TI 66-artificial temperature	
78	TI 67-artificial temperature	
79	TI 68-artificial temperature	
80	TI 69-artificial temperature	
81	TI 70-artificial temperature	
82	TI 71-artificial temperature	
83	TI 72-artificial temperature	
84	TI 73-artificial temperature	
85	TI 74-artificial temperature	
86	TI 75-artificial temperature	
87	TI 76-artificial temperature	
88	TI 77-artificial temperature	
89	TI 78-artificial temperature	
90	TI 79-artificial temperature	
91	TI 80-artificial temperature	
92	TI 81-artificial temperature	
93	TI 82-artificial temperature	
94	TI 83-artificial temperature	
95	TI 84-artificial temperature	
96	TI 85-artificial temperature	
97	TI 86-artificial temperature	
98	TI 87-artificial temperature	
99	TI 88-artificial temperature	
100	TI 89-artificial temperature	
101	TI 90-artificial temperature	
102	TI 91-artificial temperature	
103	TI 92-artificial temperature	
104	TI 93-artificial temperature	
105	TI 94-artificial temperature	
106	TI 95-artificial temperature	
107	TI 96-artificial temperature	
108	TI 97-artificial temperature	
109	TI 98-artificial temperature	
110	TI 99-artificial temperature	
111	TI 100-artificial temperature	
112	TI 101-artificial temperature	
113	TI 102-artificial temperature	
114	TI 103-artificial temperature	
115	TI 104-artificial temperature	
116	TI 105-artificial temperature	
117	TI 106-artificial temperature	
118	TI 107-artificial temperature	
119	TI 108-artificial temperature	
120	TI 109-artificial temperature	
121	TI 110-artificial temperature	
122	TI 111-artificial temperature	
123	TI 112-artificial temperature	
124	TI 113-artificial temperature	
125	TI 114-artificial temperature	
126	TI 115-artificial temperature	
127	TI 116-artificial temperature	
128	TI 117-artificial temperature	
129	TI 118-artificial temperature	
130	TI 119-artificial temperature	
131	TI 120-artificial temperature	
132	TI 121-artificial temperature	
133	TI 122-artificial temperature	
134	TI 123-artificial temperature	
135	TI 124-artificial temperature	
136	TI 125-artificial temperature	
137	TI 126-artificial temperature	
138	TI 127-artificial temperature	
139	TI 128-artificial temperature	
140	TI 129-artificial temperature	
141	TI 130-artificial temperature	
142	TI 131-artificial temperature	
143	TI 132-artificial temperature	
144	TI 133-artificial temperature	
145	TI 134-artificial temperature	
146	TI 135-artificial temperature	
147	TI 136-artificial temperature	
148	TI 137-artificial temperature	
149	TI 138-artificial temperature	
150	TI 139-artificial temperature	
151	TI 140-artificial temperature	
152	TI 141-artificial temperature	
153	TI 142-artificial temperature	
154	TI 143-artificial temperature	
155	TI 144-artificial temperature	
156	TI 145-artificial temperature	
157	TI 146-artificial temperature	
158	TI 147-artificial temperature	
159	TI 148-artificial temperature	
160	TI 149-artificial temperature	
161	TI 150-artificial temperature	
162	TI 151-artificial temperature	
163	TI 152-artificial temperature	
164	TI 153-artificial temperature	
165	TI 154-artificial temperature	
166	TI 155-artificial temperature	
167	TI 156-artificial temperature	
168	TI 157-artificial temperature	
169	TI 158-artificial temperature	
170	TI 159-artificial temperature	
171	TI 160-artificial temperature	
172	TI 161-artificial temperature	
173	TI 162-artificial temperature	
174	TI 163-artificial temperature	
175	TI 164-artificial temperature	
176	TI 165-artificial temperature	
177	TI 166-artificial temperature	
178	TI 167-artificial temperature	
179	TI 168-artificial temperature	
180	TI 169-artificial temperature	
181	TI 170-artificial temperature	
182	TI 171-artificial temperature	
183	TI 172-artificial temperature	
184	TI 173-artificial temperature	
185	TI 174-artificial temperature	
186	TI 175-artificial temperature	
187	TI 176-artificial temperature	
188	TI 177-artificial temperature	
189	TI 178-artificial temperature	
190	TI 179-artificial temperature	
191	TI 180-artificial temperature	
192	TI 181-artificial temperature	
193	TI 182-artificial temperature	
194	TI 183-artificial temperature	
195	TI 184-artificial temperature	
196	TI 185-artificial temperature	
197	TI 186-artificial temperature	
198	TI 187-artificial temperature	
199	TI 188-artificial temperature	
200	TI 189-artificial temperature	
201	TI 190-artificial temperature	
202	TI 191-artificial temperature	
203	TI 192-artificial temperature	
204	TI 193-artificial temperature	
205	TI 194-artificial temperature	
206	TI 195-artificial temperature	
207	TI 196-artificial temperature	
208	TI 197-artificial temperature	
209	TI 198-artificial temperature	
210	TI 199-artificial temperature	
211	TI 200-artificial temperature	
212	TI 201-artificial temperature	
213	TI 202-artificial temperature	
214	TI 203-artificial temperature	
215	TI 204-artificial temperature	
216	TI 205-artificial temperature	
217	TI 206-artificial temperature	
218	TI 207-artificial temperature	
219	TI 208-artificial temperature	
220	TI 209-artificial temperature	
221	TI 210-artificial temperature	
222	TI 211-artificial temperature	
223	TI 212-artificial temperature	
224	TI 213-artificial temperature	
225	TI 214-artificial temperature	
226	TI 215-artificial temperature	
227	TI 216-artificial temperature	
228	TI 217-artificial temperature	
229	TI 218-artificial temperature	
230	TI 219-artificial temperature	
231	TI 220-artificial temperature	
232	TI 221-artificial temperature	
233	TI 222-artificial temperature	
234	TI 223-artificial temperature	
235	TI 224-artificial temperature	
236	TI 225-artificial temperature	
237	TI 226-artificial temperature	
238	TI 227-artificial temperature	
239	TI 228-artificial temperature	
240	TI 229-artificial temperature	
241	TI 230-artificial temperature	
242	TI 231-artificial temperature	
243	TI 232-artificial temperature	
244	TI 233-artificial temperature	
245	TI 234-artificial temperature	
246	TI 235-artificial temperature	
247	TI 236-artificial temperature	
248	TI 237-artificial temperature	
249	TI 238-artificial temperature	
250	TI 239-artificial temperature	
251	TI 240-artificial temperature	
252	TI 241-artificial temperature	
253	TI 242-artificial temperature	
254	TI 243-artificial temperature	
255	TI 244-artificial temperature	
256	TI 245-artificial temperature	
257	TI 246-artificial temperature	
258	TI 247-artificial temperature	
259	TI 248-artificial temperature	
260	TI 249-artificial temperature	
261	TI 250-artificial temperature	
262	TI 251-artificial temperature	
263	TI 252-artificial temperature	
264	TI 253-artificial temperature	
265	TI 254-artificial temperature	
266	TI 255-artificial temperature	
267	TI 256-artificial temperature	
268	TI 257-artificial temperature	
269	TI 258-artificial temperature	
270	TI 259-artificial temperature	
271	TI 260-artificial temperature	
272	TI 261-artificial temperature	
273	TI 262-artificial temperature	
274	TI 263-artificial temperature	
275	TI 264-artificial temperature	
276	TI 265-artificial temperature	
277	TI 266-artificial temperature	
278	TI 267-artificial temperature	
279	TI 268-artificial temperature	
280	TI 269-artificial temperature	
281	TI 270-artificial temperature	
282	TI 271-artificial temperature	
283	TI 272-artificial temperature	
284	TI 273-artificial temperature	
285	TI 274-artificial temperature	
286	TI 275-artificial temperature	
287	TI 276-artificial temperature	
288	TI 277-artificial temperature	
289	TI 278-artificial temperature	
290	TI 279-artificial temperature	
291	TI 280-artificial temperature	
292	TI 281-artificial temperature	
293	TI 282-artificial temperature	
294	TI 283-artificial temperature	
295	TI 284-artificial temperature	
296	TI 285-artificial temperature	
297	TI 286-artificial temperature	
298	TI 287-artificial temperature	
299	TI 288-artificial temperature	
300	TI 289-artificial temperature	
301	TI 290-artificial temperature	
302	TI 291-artificial temperature	
303	TI 292-artificial temperature	
304	TI 293-artificial temperature	
305	TI 294-artificial temperature	
306	TI 295-artificial temperature	
307	TI 296-artificial temperature	
308	TI 297-artificial temperature	
309	TI 298-artificial temperature	
310	TI 299-artificial temperature	
311	TI 300-artificial temperature	
312	TI 301-artificial temperature	
313	TI 302-artificial temperature	
314	TI 303-artificial temperature	
315	TI 304-artificial temperature	
316	TI 305-artificial temperature	
317	TI 306-artificial temperature	
318	TI 307-artificial temperature	
319	TI 308-artificial temperature	
320	TI 309-artificial temperature	
321	TI 310-artificial temperature	
322	TI 311-artificial temperature	
323	TI 312-artificial temperature	
324	TI 313-artificial temperature	
325	TI 314-artificial temperature	
326	TI 315-artificial temperature	
327	TI 316-artificial temperature	
328	TI 317-artificial temperature	
329	TI 318-artificial temperature	
330	TI 319-artificial temperature	
331	TI 320-artificial temperature	
332	TI 321-artificial temperature	
333	TI 322-artificial temperature	
334	TI 323-artificial temperature	
335	TI 324-artificial temperature	
336	TI 325-artificial temperature	
337	TI 326-artificial temperature	
338	TI 327-artificial temperature	
339	TI 328-artificial temperature	
340	TI 329-artificial temperature	
341	TI 330-artificial temperature	
342	TI 331-artificial temperature	
343	TI 332-artificial temperature	
344	TI 333-artificial temperature	

### 3.4.Switch setting and function information



The functions of switches are as follows:

Table 3-4-1

No.		Modbus parity check		Function	
1	2	0	F	Modbus parity check	
OFF	OFF	No check		No check	
ON	OFF	4800	ON	OFF	Even parity check
OFF	ON	19200	OFF	ON	Odd parity check
ON	ON	9600	ON	ON	No check

Table 3-4-2

SW5		
No.	State	Function
1	OFF	Cooling and heating type unit
	ON	Heating only unit
2	OFF	WUI control
	ON	Thermostat control
3	OFF	Normal control (user mode)
	ON	Lab test mode (only for capacity test)
4	OFF	With domestic hot water
	ON	Without domestic hot water

Table 3-4-3

SW7				
1	2	3	4	Brand
OFF	OFF	OFF	ON	/

Table 3-4-4

SW8		
No.	State	Function
1	OFF	Modbus stop bit: 1 bit
	ON	Modbus stop bit: 2 bit
2	OFF	Reserved
	ON	Reserved
3	OFF	Reserved
	ON	Reserved
4	OFF	Refer to table 3-4-5
	ON	

Table 3-4-5


Modbus address			
SW8-4 OFF		SW8-4 ON	
SW1	Address	SW1	Address
0	32	0	16
1	1	1	17
2	2	2	18
3	3	3	19
4	4	4	20
5	5	5	21
6	6	6	22
7	7	7	23
8	8	8	24
9	9	9	25
A	10	A	26
B	11	B	27
C	12	C	28
D	13	D	29
E	14	E	30
F	15	F	31

## 4. Control logic

### 4.1. General control logic

#### 1. Communication logic

The unit has two PCBs including IDU PCB and ODU PCB. The IDU PCB is used to receive the setting parameters from controller, and then calculates the capacity demand basing on the system state, as well as feeds back the error to controller. ODU PCB is used to receive the demand signal from IDU PCB, and then controls the compressor, fan motor, valves, base-pan crank heater, etc.



## 2. Control setpoint type

To achieve better comfort, the unit can set the room temperature setpoint control or water setpoint control according to your needs. No matter air setpoint control or water setpoint control, they can both set the climate curves (also call auto mode):

### 2.1 Air setpoint control

- Set the air temperature manually to control the unit;
- Choose the climate curves to control the unit automatically according to ambient temperature.

### 2.2 Water setpoint control

- Set the water temperature manually to control the unit;
- Choose the climate curves to control the unit automatically according to ambient temperature.

## 3. Domestic hot water control

For heat pump with a domestic water tank, the DHW mode is used to produce hot water for domestic purposes. The system control manages to operation the hot domestic water tank, as well as the diverting value. The heat pump is standard fitted with a variable speed pump in a hydraulic kit, and this pump is controlled with adjustable speed according to entering water temperature and leaving water temperature.

The heat pump would control the domestic hot water according to schedule or priority mode;

### 3.1 Schedule

If set the schedule of domestic hot water, then the heat pump would run DHW mode according schedule and DHW demand together.

Table 4-1-1

DHW schedule configure	Schedule days	Select the days for operating DHW mode Monday/Tuesday/Wednesday/Thursday/Friday/Saturday/Sunday
	Starting time	Time of starting up DHW mode (00:00 to 23:59)
	Stopping time	Time of stop DHW mode (00:00 to 23:59)

### 3.2 Priority mode

If the set the DHW mode as priority mode, then the heat pump would run the DHW mode according the DHW demand only.

## 4. Anti-legionella control

In order to protect the health of human, it must have the anti-legionella function once configure the domestic hot water. The anti-legionella function is controlled to turn on/off according to the temperature of the domestic hot water and schedule or manually by controller.

If set the schedule of anti-legionella, then the heat pump would run anti-legionella according schedule and setpoint, and will exit this function after running for 3h or reaching the setpoint.

Table 4-1-2

Anti-legionella configure	Schedule days	Select the days for operating DHW mode Monday/Tuesday/Wednesday/Thursday/Friday/Saturday/Sunday
	Starting time	Time of starting up anti-legionella function (00:00 to 23:59)
	Setpoint	Temperature value of stop anti-legionella function (60 to 70°C)

## 4.2. Start up control

### 1. Compressor startup delay control

In initial startup control and in restart control (except defrosting operation), compressor startup is delayed 3 minimums in order to prevent frequent compressor on/off and to equalize the pressure within the refrigerant system.


### 2. Compressor startup program

In initial startup control and in re-start control, compressor startup is controlled according to outdoor ambient temperature and discharged temperature. Compressor startup follows one of two startup programs until the target rotation speed is reached.

When it meets one of the below conditions, the heat pump will start with startup program I, otherwise the heat pump starts with startup program II.


- Discharged temperature  $\geq 15^{\circ}\text{C}$ ;
- Outdoor ambient temperature  $\geq 3^{\circ}\text{C}$ .

Startup program I:



Picture 4-2-1 Startup program I

Startup program II



Picture 4-2-2 Startup program II

Note: If the target frequency is lower than plat frequency, then the heat pump would not complete the whole startup plat program.

### 3. State and control of components

Startup control for cooling operation

Table 4-2-1

Components	4-16kW	Control functions and states	Note
Inverter compressor	•	Compressor startup program according to T4 and Td. <sup>1</sup>	TP: Discharged temp. T4: Outdoor ambient temp. T3: Outdoor coil temp.
DC fan motor	•	Fan motor startup with speed W7. <sup>2</sup>	
Electronic expansion valve	•	0-480 pules, start with a certain opening degree, and controlled according to compressor frequency, TP, T4 and T3.	
4-way valve	•	OFF	

Startup control for heating and domestic hot water operation

Table 4-2-2

Components	4-16kW	Control functions and states	Note
Inverter compressor	•	Compressor startup program according to ambient temperature and discharged temperature. <sup>1</sup>	TP: Discharged temp. T4: Outdoor ambient temp. LWT: Leaving water temp.

DC fan motor	•	Fan motor startup with speed W7. <sup>2</sup>	
Electronic expansion valve	•	0-480 pules, start with a certain opening degree, and controlled according to compressor frequency, TP, T4 and LWT.	
4-way valve	•	ON	

Note:

1. Refer to section 4.2 startup control, part 2 compressor startup control, picture 4-2-1 & picture 4-2-2.
2. Refer to section 4.3 normal operation control, part 5 “outdoor fan control”, table 4.3-3.

### 4.3.Normal operation control

#### 1. Component control during operation

Normal operation control in cooling mode

Table 4-3-1

Components	4-16kW	Control functions and states	Note
Inverter compressor	•	Compressor frequency is controlled according to requirement of hydraulic kit and T4.	TP: Discharged temp. T4: Outdoor ambient temp. T3: Outdoor coil temp.
DC fan motor	•	Fan motor speed is controlled according to TP, T3 and T4.	
Electronic expansion valve	•	0-480 pules, start with a certain opening degree, and controlled according to compressor frequency, TP, T4 and T3.	
4-way valve	•	OFF	

Normal operation control in heating and domestic hot water mode

Table 4-3-2

Components	4-16kW	Control functions and states	Note
Inverter compressor	•	Compressor frequency is controlled according to requirement of hydraulic kit and T4.	TP: Discharged temp. T4: Outdoor ambient temp. T3: Outdoor coil temp. LWT: Leaving water temp.
DC fan motor	•	Fan motor speed is controlled according to compressor frequency, T3 and T4.	
Electronic expansion valve	•	0-480 pules, start with a certain opening degree, and controlled according to compressor frequency, TP, T4 and LWT.	
4-way valve	•	ON	

#### 2. Compressor control

The compressor rotation speed is controlled according to the load requirement and ambient temperature. Before compressor startup, the heat pump unit determines the compressor target speed according to outdoor ambient temperature, leaving water setting temperature and actual leaving water temperature and then runs the appropriate compressor startup program. Refer to section 4.2, Part 2 “Compressor Startup Program”. Once the startup program is completed, the compressor runs at the target rotation speed.

During operation the compressor speed is controlled according to the difference between setting temperature and actually leaving water temperature, outdoor ambient temperature, and limited by the refrigerant temperature, running current, and power supply voltage.

#### 3. 4-way valve control

The four-way valve is used to change the direction of refrigerant flow through the water side heat exchanger in

order to switch between cooling and heating/DHW operations.

During heating and DHW operations, the four-way valve is on; during cooling and defrosting operations, the four-way valve is off.

#### 4. Electronic expansion valve control

The position of the electronic expansion valve is controlled from 0 (full closed) to 480 (full open).

- After power-on  
The EXV first closes fully, then moves to standby position.  
When it is running cooling mode, then the EXV changes to initial position for a few mins, and is controlled according to compressor frequency, outdoor ambient temperature, discharged temperature and condenser temperature.  
When it is running heating/DHW mode, then the EXV changes to initial position for a few mins, and is controlled according to compressor frequency, outdoor ambient temperature, discharged temperature and leaving water temperature.
- When unit in standby mode  
The EXV is at standby position.
- When unit is stopped  
The EXV first closes fully, then moves to standby position.

#### 5. Outdoor fan control

The outdoor fan speed is controlled and adjusted according to following table.

Table 4-3-3

Fan speed	4-10kW (RPM)	12-16kW (RPM)	
		Up motor	Down motor
0	0	0	0
W1	250	250	310
W2	330	330	410
W3	430	430	510
W4	530	530	610
W5	630	630	710
W6	730	730	760
W7	780	780	840
W8	860	860	860

#### 6. Water pump control

The inverter pump will start 60s before compressor running, and delay 120s to close after turning off the heat pump or reaching the setting temperature. This inverter water pump adjust the speed from 30% to 100% according to the entering water temperature and leaving water temperature.

#### 7. Spray liquid cooling control

When the discharged temperature of compressor exceeds 100°C, the solenoid valve opens and the frequency of compressor drops in order to reduce the discharged temperature. When the discharged temperature is below 90°C, the solenoid valve closes.

#### 4.4. Stop control

The stop operation occurs for one of the following reasons:

1. The system stops when the set temperature has been reached.
2. Abnormal shutdown: in order to protect the system, if an abnormal state occurs the system a ‘stop with thermo off’ operation and an error code is displayed on the PCB digital display and on the user interface.

## 4.5. Standby control

### 1. Compressor crank heater control

The crank heater is used to prevent refrigerant from mixing with compressor oil when is stopped. It is controlled according to the outdoor ambient temperature and the compressor on/off state.

When the outdoor ambient temperature is above 0°C or compressor is running, the crank heater is off;

When the outdoor ambient temperature is below or at 0°C and either the compressor has been stopped for 30mins or the has just been powered-on (either manually or when the power has returned following a power outage), or when the outdoor ambient temperature is below or at -5°C and either compressor has been stopped, the crank heater turns on.

### 2. Water pump control

When the unit is in standby, the internal and external circulator pumps run according to anti-frozen logic.

## 4.6. Protection control


### 1. Pressure protection

The system equips with high-pressure and low-pressure switches to protect the system from abnormal pressure.

- High pressure protection

This protection is used to protect the refrigerant system from abnormally high pressure and protect compressor from transient spikes in pressure.

When the discharge pressure rises above 4.4MPa the system displays P1 protection and the unit stops running. When the discharge pressure drops below 3.2MPa, the compressor enters re-start control.



Picture 4-6-1

Note: Pc is the discharged


pressure.

- Low pressure

This protection is refrigerant system from and protects the transient drops in

pressure. protection used to protect the abnormally low pressure compressor from pressure.

When the suction pressure drops below 0.05MPa the system displays P2 protection and the unit stops running. When the suction pressure rises above 0.15MPa, the compressor enters re-start control.



Picture 4-6-2

Note: Ps is the suction

pressure.

### 2. Current protection


This control protects the abnormally high currents.

When the compressor current the system displays P3 protection and the unit stops running. When the compressor current drops below

compressor from

current rises above max.

max. current, the compressor enters re-start control.



Picture 4-6-3

Note: Cm is the max. current.

Table 4-6-1

Capacity	4-6kW 1Ph		12kW 1Ph		12kW 3Ph	14-16kW 3Ph
	AC	DC				
AC	18	22	25	30		
CF ≥ 60Hz	15	18	20	22		
40 ≤ CF < 60	14	17	19	21		
CF < 40	13	16	18	20		


Note: CF is the compressor frequency, Hz.

### 3. Overheat protection

- Condenser temperature overheat

This control protects the system from abnormally high temperature.

When the outdoor condenser temperature rises above 60°C the system will be under protection and the unit stops running. When the discharge temperature drops below 53°C, the compressor enters re-start control.




Picture 4-6-4

Note: T3 is the temperature.

- Compressor temperature

This control protects the compressor from abnormally high temperatures and transient spikes in temperature.

When the discharge temperature rises above 115°C the system displays P4 protection and the unit stops running. When the discharge temperature drops below 105°C, the compressor enters re-start control.



Picture 4-6-5


Note: TP is the

temperature.

- IPM board overheat

This control protects the IPM board from abnormally high temperature.

When the IPM board temperature rises above 93°C the system will be under protection and the unit stops running. When the discharge temperature drops below 68°C, the compressor enters re-start control.



Picture 4-6-6  
Note: T9 is the temperature.


IPM board

#### 4. Voltage

When the phase power supply is at or for more than 30

seconds, the system displays E9 protection and the unit stops running. When the phase voltage drops below 270V for more than 30 seconds, the refrigerant system restarts once the compressor re-start delay has elapsed. When the phase voltage is at or below 160V, the system displays H7 protection and the unit stops running. When the AC voltage rises to at or more than 165V, the refrigerant system restarts once the compressor re-start delay has elapsed.

protection voltage of AC above 275V seconds,



Picture 4-6-7

#### 4.7.Special

##### 1. Defrosting

In order to recover the defrosting operation when the outdoor unit exchanger is performing The defrosting operation according to outdoor ambient temperature, air side heat exchanger refrigerant outlet temperature and the compressor running time.

control control heating capacity, is conducted air side heat as a condenser. is controlled

Table 4-7-1

Components	4-16kW	Control functions and states
Inverter compressor	•	Compressor runs at defrosting rotation speed
DC fan motor	•	OFF.
Electronic expansion valve	•	Fully open.
4-way valve	•	OFF

##### 2. Anti-frozen control

This control is used to protect the water system from low ambient temperature or low water temperature to against the damaging the water system such as BPHE, water pipe, etc. It operates according to the ambient temperature, running mode, water temperature. During the anti-frozen, unit will display “d0”.

Table 4-7-2

Condition	Water	Unit	Electronic heaters	External	Exit
-----------	-------	------	--------------------	----------	------

Mode	Temperature	pump			heat source	
Standby	$T4 < 7^{\circ}\text{C}$ & $T\text{-ai} \leq 3^{\circ}\text{C}$	ON	Run heating mode	Inner EHs: ON DHW EHs: ON Anti-frozen EHs: ON	ON	$T4 \geq 7^{\circ}\text{C}$ or $T\text{-ai} \geq 25^{\circ}\text{C}$
Heating	$T4 \leq 3^{\circ}\text{C}$ & $T\text{-ai} \leq 3^{\circ}\text{C}$	ON	Run heating mode	Inner EHs: ON DHW EHs: ON Anti-frozen EHs: ON	ON	$T4 \geq 7^{\circ}\text{C}$ or $T\text{-ai} \geq 25^{\circ}\text{C}$
Cooling	$T\text{-ai} \leq 3^{\circ}\text{C}$	ON	Run heating mode	Inner EHs: ON DHW EHs: ON Anti-frozen EHs: ON	ON	$T\text{-ai} \leq 10^{\circ}\text{C}$

Note: Inner EHs which includes 3 electrical heaters, 3kw is standard equipment in the unit, another two is field supply if configuring.

The inner heaters & DHW heaters as well as external heat source are belonged to back up, which needs configurate first, otherwise, it will be off always.

T-ai is the min. one of the T1, Tw-in, Tw-out

T1: Leaving water temperature of unit

Tw-in: Entering water temperature of BPHE

Tw-out: Leaving water temperature of BPHE

T4: Outdoor ambient temperature.

### 3. Night mode control

The aim of this function is to reduce the noise emitted by the heat pump during the night. When night mode is configurated, the unit will limit its max. compressor speed within 76Hz and fan speed within W6.

Table 4-7-3

Night mode configurate	Function activate	0-Inactivate; 1-Activate
	Starting time	The time of start night mode (00:00-23:59)
	Exiting time	The time of exit night mode (00:00-23:59)

### 4. Base-pan crank heater control

This control is used to heat the base pan according to ambient temperature in order to drainage the water out the base-pan successful with only one drainage hole in the base-pan. The control of the base-pan crank heater is as below:

Start conditions: (meet all below conditions)

- Unit is running heating mode
- Compressor is running
- Outdoor ambient is below  $-9^{\circ}\text{C}$

Exit condition: (meet one of the below conditions)

- Unit is running cooling mode
- Compressor is stopped
- Outdoor ambient is above  $-7^{\circ}\text{C}$

### 5. Backup control

The aim of the backup function is to heat the water loop in case the heat pump capacity is not sufficient to heat the water in the low ambient temperature or failure. The backup control includes inner electrical heaters of main water loop, DHW electrical heaters in DHW tank, gas boiler. These works as booster simultaneously with heat pump or as backup alone while heat pump is stopped. They are activated according to outdoor ambient temperature, compressor running time and temperature difference between water setpoint and actually water temperature.

Table 4-7-4

Backup type	0- Inner EHs of main water loop + DHW EHs + boiler 1- Inner EHs of main water loop + DHW EHs 2- DHW EHs + boiler 3- Inner EHs of main water loop + boiler 4- DHW EHs only 5- Boiler only 6- Inner EHs of main water loop only
-------------	---

	7- Non back up
Minimum OAT for heating	-26~10°C, default as -26°C
Booster OAT threshold	-10~0°C, default as -5°C
Heat pump warm up time	0~120min, default 60min
Booster Delta temperature	1~20°C, default as 10°C

Note: Inner EHs which includes 3 electrical heaters, 3kw is standard equipment in the unit, another two is field supply if configuring.

EHs: Electrical heaters

OAT: Outdoor ambient temperature

DHW: Domestic hot water.

## 6. Dry contact control

The heat pump equips with contact to control the system in order to match different controlled requirements.

It equips with 3 dry contacts as standard and 4 dry contacts as customized, as well as 3 standard output contacts and 3 customized outputs which are 230V output terminals.

The details of the contact function are shown as below table:

Table 4-7-5

Standard	DI1	ON / OFF operation
	DI2	Cooling mode / heating mode operation
	DI3	Home / away operation
	DO1	Unit is in operating state
	DO2	Unit is defrosting
	DO3	Unit is in alarm
Customized	DI1	0- Disable 1- Power limitation (Night mode activate)
	DI2	2- Load-shed electrical heaters
	DI3	3- Domestic hot water request
	DI4	4- Anti-legionella request
		5- Domestic hot water priority
	DO1	0- Disable 1- Unit is in alarm 2- Unit is in standby mode
	DO2	3- Unit is running 4- Unit is in cooling mode 5- Unit is in heating mode
DO3	6- Unit is in domestic hot water mode 7- Unit is defrosting 8- Unit is controlled by Modbus	

### 4.8.Function table of sensors

The location of the sensors is as below:




Table 4-8-1

Sensor code	Sensor name	Mode	Function of sensor
T1	Leaving water temperature sensor of unit	Cooling	• Capacity request control
		Heating	• Backup control
		DHW	• Anti-frozen control
TW-i	Entering water temperature sensor of BPHE	Heating	• Anti-frozen control
		DHW	
TW-o	Leaving water temperature sensor of BPHE	Cooling	• Capacity request control
		Heating	• Backup control
		DHW	• Anti-frozen control
T1B	External heat source leaving water temperature sensor	Heating	• External heat source control
T2B	Refrigerant sensor of BPHE	Cooling	• Compressor frequency control • Anti-freezing protection control
T5	Domestic hot water temperature sensor	DHW	• DHW capacity control • Anti-legionella control
TP	Discharged temperature sensor	Cooling	• Compressor frequency control
		Heating	• Expansion valve control
		DHW	
T3	Outdoor coil temperature sensor	Cooling	• Compressor frequency control
		Heating	• Expansion valve control
		DHW	• DC fan motor speed control • Defrost control
T4	Outdoor ambient temperature sensor	Cooling	• Compressor frequency control
		Heating	• DC fan motor speed control
		DHW	• Expansion valve control • Defrost control
T6	Indoor ambient temperature sensor	Cooling	• Capacity request control by ambient
		Heating	
		DHW	-
T7	IPM board cooling	Cooling	• Compressor frequency control

	pipe temperature sensor	Heating	• DC fan motor speed control
		DHW	
T9	IPM board temperature sensor	Cooling	• Compressor frequency control • DC fan motor speed control
		Heating	
		DHW	

## 5. Troubleshooting

### 5.1. Error code

#### 1. General presentation

For the error, here are two display devices: one is the user interface and the other is the IDU PCB digital tube. It must pay attention to the error where it is displayed to get the correct meaning of the problem.

#### 2. Error code list of user interface

Table 5-1-1

Alarm code	Description
E0	Water flow switch fault
E1	Communication fault between IDU board and ODU board
E2	LWT of unit sensor (T1 sensor) fault
E3	Gas refrigerant temp sensor (T2 sensor) fault (reserved)
E4	Liquid refrigerant temp sensor (T2B sensor) fault
E5	ODU (module part) alarm
E6	DHW sensor (T7 sensor) fault
E7	EWT sensor (Tw <sub>in</sub> sensor) fault
E8	LWT of BPHE sensor (Tw <sub>out</sub> sensor) fault
E9	Communication fault between WUI and function board
EA	Second zone LWT sensor (Tw <sub>2</sub> sensor) fault (Only valid after setting second zone function, reserved)
Eb	External heat source LWT sensor (T1B sensor) fault (Only valid after set the external heat source – boiler)
Ec	Reserved
Ed	Reserved
EE	Reserved
EF	Mode conflict (reserved)
P0	EEPROM fault
P1	Protection of huge different values between EWT and LWT
P2	Protection of lack of water
P3	Protection of abnormal different value between EWT and LWT
P6	Protection of the standard electrical heater over heat

Note:

1. When it is displayed the E5-ODU alarm, that needs to check the alarm on the IDU PCB for more detail.
2. P0-P3 will only be displayed after it occurs 3 times in 1h, and can't resume unless repower the system.

### 3. Error code list of IDU PCB

Table 5-1-2

Alarm code	Description
E1	Phase sequence fault
E2	Communication fault between IDU PCB and ODU PCB
E4	T4 ambient temperature sensor fault
E6	T3 ODU condenser temperature sensor fault
E8	TP discharged temperature sensor fault
E9	Power supply voltage over-high/over-low protection
E10	EPPROM fault
Ec	T7 refrigerant cooling pipe temperature sensor fault
H0	Communication fault between main chip of ODU PCB and module chip of ODU PCB
H4	3 times P6 error in 30mins
H5	3 times P2 error in 30mins
H6	3 times P4 error in 100mins
H7	IDU quantity decrease alarm (reserved)
H9	2 times P9 error in 10mins
H10	3 times P3 error in 60mins
H11	2 times P13 error in 10mins (reserved)
H12	3 times Pb error in 60mins
P1	High pressure protection
P2	Low pressure protection
P3	Over current protection
P4	Over-heat protection of discharged temperature
P5	Condenser over-heat protection
P6	IPM board protection
P9	DC motor protection
P10	Anti-typhoon protection (reserved)
P11	T2B refrigerant temperature of HPHE over-low protection
Pb	IPM temperature over-heat protection

Note: The error H4-H12 must repower to resume.

## 5.2. Running parameter checking

### 1. General presentation

For the running parameter checking, here are two devices to check the value: one is the user interface and the other is the IDU PCB digital tube.

### 2. Parameter checking from user interface

Press the “query” button to go into the parameter query interface, and press “confirm” button or without pressing any button for more than 10s to exit the parameter query interface.

After going into query interface, press “up” or “down” button to check the parameters or status as follow table:

-  : Query button;
-  : Confirm button
-  : Up button
-  : Down button



Picture 5-2-1

Table 5-2-1

No.	Definition	Description
1	Setting temp.: Ts1	Display Ts1 during standby/cool/heat mode
2	Setting temp.: Ts2	Display Ts2 during DHW mode
3	Setting temp.: Ts3	Display Ts3 when it chooses the air setpoint control
4	Capacity of unit	HP*10, example: 10 means that unit is 1HP capacity
5	Target frequency	
6	Running frequency	
7	Water flow rate	m <sup>3</sup> /h, feedback from inverter water pump
8	Capacity output	=1.163* (water flow rate) * [Tw out – Tw in] (kW)
9	T3 value	ODU coil temp.
10	T4 value	OAT
11	TP value	Discharged temp.
12	T7 value	Temp. of refrigerant for PCB cool
13	EVX opening degree	Actually value
14	ODU fan motor speed	
15	AC current	
16	AC voltage	
17	IPM temp. (T9)	Compressor module temp.
18	Limitation reason of compressor frequency	0: no limitation; 1: T3B temp. limitation (reserved); 2: OAT limitation; 4: Discharged temp. limitation; 8: Voltage limitation

		16: Current limitation 32: IPM temp' limitation 64: Night mode limitation 128: LWT limitation If occur multi limitation, display value=sum of all limitation value
19	Limitation reason of compressor frequency	0: no limitation; 1: Limitation of different value between EWT&LWT
20	Tw in value	EWT
21	Tw out value	LWT of BPHE
22	T1 value	LWT of unit (after the EHs inside the unit)
23	T6 value	IAT, the sensor built inside the wired controller
24	T5 value	DHW value
25	Tw-2 value	Second zone EWT value when set this function (reserved)
26	T1B value	External heat source (boiler) LWT value
27	Capacity demand	
28	Inv. Pump speed	
29	Last alarm	
30	Penult alarm	
31	Antepenultimate alarm	
32	Current protection	P0-P3: check the detail in alarm table
33	Detail of P6 alarm in function board	L-: no alarm; L0: IPM or IGBT over current; L1: lack of phase L2: Compressor losing speed fault; L3: DC voltage is too low to protect L4: Fan motor over current protection L5: Fan motor lack of phase; L6: Fan motor zero speed fault L7: PFC fault L8: DC voltage is too high to protect L9: Compressor zero speed fault LA: PWM synchronization fault Lb: MCE fault Lc: Compressor over current protection Ld: EEPROM data is wrong LE: Compressor fail to start; LF: fan motor losing speed fault
34	SV2 statue of water loop	2-way valve which is used to change the cool/heat water between fan coil and radiator (OFF-0; ON-1)
35	SV3 statue of water loop	DHW 3-way valve
36	Main water loop EHs statue	Standard equip with one EH, another two are field supply (OFF-0; ON-1)
37	DHW EHs	OFF-0; ON-1
38	External heat source statue	OFF-0; ON-1
39	P o	External main water loop pump (OFF-0; ON-1)
40	P p	Second zone water loop pump (OFF-0; ON-1)
41	P m	External heat source water loop pump (OFF-0; ON-1)
42	Anti-frozen heater statue	OFF-0; ON-1
43	Chassis heater statue	OFF-0; ON-1
44	Crank heater statue	OFF-0; ON-1
45	SV2 statue of refrigerant system	Liquid spray cool value (OFF-0; ON-1)

### 3. Parameter checking from IDU PCB


Press “up” or “down” button to check the parameters or status as follow table:



: Up button



: Down button



Picture 5-2-2

Table 5-2-2

No.	Definition	Description
0	Frequency/QTY of IDU	Display the qty of IDU while standby/display frequency while running
1	The capacity of unit	
2	Capacity demand of IDU	
3	Capacity demand after ODU amending	
4	Running mode	0-OFF; 2-cooling; 3-heating; 4-force heating
5	Actual output of ODU	
6	Fan speed	0-8
7	Tw-in value	EWT of BPHE
8	Tw-out value	LWT of BPHE
9	T1 value	LWT of unit after electrical heater
10	T3 value	ODU condenser temperature
11	T4 value	ODU ambient temperature
12	TP value	Discharged temperature
13	EVX opening degree	Actually value = display value * 4
14	T7 value	Temperature of refrigerant cooling pipe
15	AC current	
16	DC current	
17	AC voltage	
18	DC voltage	
19	Last error	It will display “---” if no error had occurred
20	Limitation reason of compressor frequency	0: no limitation; 1: T3B temp. limitation (reserved); 2: OAT limitation; 4: Discharged temp. limitation; 8: Voltage limitation 16: Current limitation 32: IPM temp’ limitation 64: Night mode limitation 128: LWT limitation If occur multi limitations, display value=sum of all limitation value
21	Version of ODU software	
22	Version of EPPROM	
23	Detail of P6 alarm in function board	L-: no alarm; L0: IPM or IGBT over current; L1: lack of phase

		L2: Compressor losing speed fault; L3: DC voltage is too low to protect L4: Fan motor over current protection L5: Fan motor lack of phase; L6: Fan motor zero speed fault L7: PFC fault L8: DC voltage is too high to protect L9: Compressor zero speed fault LA: PWM synchronization fault Lb: MCE fault Lc: Compressor over current protection Ld: EEPROM data is wrong LE: Compressor fail to start; LF: fan motor losing speed fault
24	T9 value	IPM board temperature
25	T30	Target T3 value for defrost control
26	Limitation reason of compressor frequency	0- no limitation; 1- limitation due to huge different value between EWT&LWT
27	Target discharged temperature	
28	ODU CRCH	Hex.
29	ODU CRCL	Hex.
30	IDU CRCH	Hex.
31	IDU CRCL	Hex.
32	Modbus baud rate	
33	Modbus parity check	0-non; 1-odd parity check; 2-even parity check
34	Modbus ID	1-255
35	Last 1 <sup>st</sup> error	
36	Last 2 <sup>nd</sup> error	
37	Last 3 <sup>rd</sup> error	
38	Last 4 <sup>th</sup> error	
39	Last 5 <sup>th</sup> error	
40	Last 6 <sup>th</sup> error	
41	Last 7 <sup>th</sup> error	
42	Last 8 <sup>th</sup> error	
43	Last 9 <sup>th</sup> error	
44	Last 10 <sup>th</sup> error	
45	T2B refrigerant sensor temp.	The refrigerant pipe temp. of BPHE

### 5.3.Troubleshooting

#### 1. Troubleshooting for error of user interface

Table 5-3-1

Alarm code	Description
E0	Water flow switch fault
E1	Communication fault between IDU board and ODU board
E2	LWT of unit sensor (T1 sensor) fault
E3	Gas refrigerant temp sensor (T2 sensor) fault (reserved)
E4	Liquid refrigerant temp sensor (T2B sensor) fault
E5	ODU (module part) alarm
E6	DHW sensor (T7 sensor) fault
E7	EWT sensor (Tw in sensor) fault
E8	LWT of BPHE sensor (Tw out sensor) fault
E9	Communication fault between WUI and function board
EA	Second zone LWT sensor (Tw_2 sensor) fault (Only valid after setting second zone function, reserved)
Eb	External heat source LWT sensor (T1B sensor) fault (Only valid after set the external heat source – boiler)
Ec	Reserved
Ed	Reserved
EE	Reserved
EF	Mode conflict (reserved)
P0	EEPROM fault
P1	Protection of huge different values between EWT and LWT
P2	Protection of lack of water
P3	Protection of abnormal different value between EWT and LWT

## E0: Water flow switch fault


### Description:

It will occur when the water flow rate is below 0.72m<sup>3</sup>/h, and the unit would stop, then giving the error “E0” on the user interface.

### Possible causes:

- Water pump or water system jam
- Water flow switch damage
- IDU PCB damage

### Procedure



**E1: Communication fault between IDU board and ODU board**


**Description:**

It will occur when the IDU PCB and ODU PCB loose communication more than 2mins, and the unit would stop, “E1” display on the user interface.

**Possible causes:**

- Communication cable do not connect firmly or damage
- ODU PCB damage
- IDU PCB damage
- User interface damage

**Procedure**



**E2: LWT of unit sensor (T1 sensor) fault**


**Description:**

The IDU PCB can not read the normal value of T1 sensor, and the unit keeps run, “E2” display on the user interface.

**Possible causes:**

- The T1 sensor is loose or short-circuit/open-circuit
- IDU PCB damage
- User interface damage

**Procedure:**



**E4: Liquid refrigerant temp. sensor of BPHE (T2B sensor) fault**


**Description:**

The IDU PCB can not read the normal value of T2B sensor, and the unit keeps run, “E4” display on the user interface.

**Possible causes:**

- The T2B sensor is loose or short-circuit/open-circuit
- IDU PCB damage
- User interface damage

**Procedure:**



### E5: ODU (module part) alarm


#### Description:

The ODU part has error, and “E5” displays on the WUI. It needs to check the detail error from IDU PCB.

#### Possible causes:

- ODU part happens with error, need to check the details from IDU PCB.

#### Procedure:



## E6: DHW sensor (T5 sensor) fault


### Description:

The IDU PCB can not read the normal value of T5 sensor, and the unit can not run DHW mode, “E6” display on the user interface.

### Possible causes:

- The T5 sensor is loose or short-circuit/open-circuit
- IDU PCB damage
- User interface damage

### Procedure:



## E7: Entering water temp. sensor (Tw-in sensor) fault


### Description:

The IDU PCB can not read the normal value of Tw-in sensor, and the unit can not run, “E7” display on the user interface.

### Possible causes:

- The Tw-in sensor is loose or short-circuit/open-circuit
- IDU PCB damage
- User interface damage

### Procedure:



**E8: Leaving water temp. sensor of BPHE (Tw-out sensor) fault**


**Description:**

The IDU PCB can not read the normal value of Tw-out sensor, and the unit can not run cooling mode, “E8” display on the user interface.

**Possible causes:**

- The Tw-out sensor is loose or short-circuit/open-circuit
- IDU PCB damage
- User interface damage

**Procedure:**





**Eb: External heat source (gas boiler) LWT sensor (T1B sensor) fault**


**Description:**

The WUI loses the communication with the IDU PCB, and “Eb” is displayed on the user interface.

**Possible causes:**

- The Tw-in sensor is loose or short-circuit/open-circuit
- IDU PCB damage
- User interface damage

**Procedure:**



## **P0: EEPROM fault**

### **Description:**

The EEPROM parameter can not be read with correct value, and “P0” is displayed on the user interface.

### **Possible causes:**

- The EEPROM is damaged
- IDU PCB damage

### **Procedure:**

P0   N
Replace the IDU board

## P1: Protection of huge different value between EWT and LWT

### Description:

The tolerance between LWT and EWT is quite big, and P1 is displayed on the user interface.


$\Delta T \geq 13^\circ\text{C}$  for 60s in cooling mode

$\Delta T \geq 20^\circ\text{C}$  for 60s in heating/DHW mode

### Possible causes:

- The Tw-in sensor and Tw-out sensor are loose or damaged to get wrong data
- The water flow rate is not enough
- The IDU PCB is damaged

### Procedure:



- If all above steps are done, still P1 error, replace the IDU PCB.

**P2: Protection of lack of water flow**


**Description:**

When water pump starts for 100s, it start to detect the water flow rate by the water flow switch. It will occur when the water flow rate is below 0.72m<sup>3</sup>/h, and the unit would stop, then giving the error “P2” on the user interface.

**Possible causes:**

- Water pump or water system jam
- Water flow switch is installed in opposite
- Water flow switch damage
- IDU PCB damage

**Procedure**



**P3: Protection of abnormal different value between EWT and LWT**

**Description:**

The tolerance between LWT and EWT is quite big, and P1 is displayed on the user interface.


After running cooling mode for 10mins,  $\Delta T \leq 0^\circ\text{C}$  ( $\Delta T = T_{w-in} - T_{w-out}$ )

After running heating/DHW mode for 10mins,  $\Delta T \leq 0^\circ\text{C}$  ( $\Delta T = T_{w-out} - T_{w-in}$ )

**Possible causes:**

- The Tw-in sensor and Tw-out sensor are installed opposite
- The Tw-in sensor and Tw-out sensor are loose or damaged to get wrong data
- The water pump is installed opposite
- The 4-way valve is not working correct
- The IDU PCB is damaged

**Procedure:**



- Reconnect the sensor firmly, if not solve, replace the IDU PCB
- Check the LWT sensor is connected to Tw-o port, EWT sensor is connected to Tw-o port, otherwise go to next step;
- Check the water pump is installed in right direction or not,
- Check the 4-way valve is operation correct in cooling mode, if not in correct operation, replace the 4-way valve.
- If all the above steps are done, replace the PCB.

correct  
lled

## 2. Troubleshooting for error of IDU PCB

Table 5-3-2

Alarm code	Description
E1	Phase sequence fault
E2	Communication fault between IDU PCB and ODU PCB
E4	T4 ambient temperature sensor fault
E6	T3 ODU condenser temperature sensor fault
E8	TP discharged temperature sensor fault
E9	Power supply voltage over-high/over-low protection
E10	EPPROM fault
Ec	T7 refrigerant cooling pipe temperature sensor fault
H0	Communication fault between main chip of ODU PCB and module chip of ODU PCB
H4	3 times P6 error in 30mins
H5	3 times P2 error in 30mins
H6	3 times P4 error in 100mins
H7	IDU quantity decrease alarm (reserved)
H9	2 times P9 error in 10mins
H10	3 times P3 error in 60mins
H11	2 times P13 error in 10mins (reserved)
H12	3 times Pb error in 60mins
P1	High pressure protection
P2	Low pressure protection
P3	Over current protection
P4	Over-heat protection of discharged temperature
P5	Condenser over-heat protection
P6	IPM board protection
P9	DC motor protection
P10	Anti-typhoon protection (reserved)
P11	T2B refrigerant temperature of HPHE over-low protection
Pb	IPM temperature over-heat protection

**E1 : Phase sequence fault**


**Description:**

The sequence of the power supply is not correct, and the “P1” displays on the IDU PCB.

**Possible causes:**

- The power connection cable is in wrong sequence
- The 3-phase power supply has problem
- The IDU PCB is fault

**Procedure:**



## E2: Communication fault between IDU PCB and ODU PCB


### Description:

It will occur when the IDU PCB and ODU PCB loose communication more than 2mins, and the unit would stop, "E2" display on the IDU PCB.

### Possible causes:

- Communication cable do not connect firmly or damage
- ODU PCB damage
- IDU PCB damage

### Procedure



### E4: Outdoor ambient temperature sensor (T4 sensor) fault


#### Description:

The ODU PCB can not read the normal value of T4 sensor, and the unit stops running, “E4” display on the IDU PCB.

#### Possible causes:

- The T4 sensor is loose or short-circuit/open-circuit
- IDU PCB damage
- ODU PCB damage

#### Procedure:



er to n the re  
nsor, otherwise go  
not solve, replace the IDU PCB, otherwise go to the next step

## E6: ODU condenser temperature sensor (T3 sensor) fault


### Description:

The ODU PCB can not read the normal value of T3 sensor, and the unit stops running, “E6” display on the IDU PCB.

### Possible causes:

- The T3 sensor is loose or short-circuit/open-circuit
- IDU PCB damage
- ODU PCB damage

### Procedure:



## E8: Outdoor discharged temperature sensor (TP sensor) fault


### Description:

The ODU PCB can not read the normal value of TP sensor, and the unit stops running, “E8” display on the IDU PCB.

### Possible causes:

- The TP sensor is loose or short-circuit/open-circuit
- IDU PCB damage
- ODU PCB damage

### Procedure:



## E9: Power supply voltage over-high/over-low protection


### Description:

The IDU PCB detects that the power supply voltage is over 275V or below 160V for single phase, "E9" display on the IDU PCB.

### Possible causes:

- The power supply is not correct
- The power cable is not connected well or damaged
- IDU PCB damage

### Procedure:



## **E10: EEPROM fault**

### **Description:**

The EEPROM parameter can not be read with correct value, and “E10” is displayed on the IDU PCB.

### **Possible causes:**

- The EEPROM is damaged
- ODU PCB damage

### **Procedure:**

E10   N
Replace the ODU board

**Ec: Refrigerant cooling pipe temperature sensor (T7 sensor) fault**


**Description:**

The ODU PCB can not read the normal value of T7 sensor, and the unit stops running, “Ec” display on the IDU PCB.

**Possible causes:**

- The T7 sensor is loose or short-circuit/open-circuit
- IDU PCB damage
- ODU PCB damage

**Procedure:**



**H0: Communication fault between main chip and module chip of ODU PCB**

**Description:**

The main chip of ODU PCB and the module chip of ODU PCB is loose communication, which need to replace the ODU PCB.

**H4: 3 times P6 error in 30mins**

**Description:**

Refer to P6.

**H5: 3 times P2 error in 30mins**

**Description:**

Refer to P2.

**H6: 3 times P4 error in 100mins**

**Description:**

Refer to P4.

**H9: 2 times P9 error in 10mins**

**Description:**

Refer to P9.

**H10: 3 times P3 error in 60mins**

**Description:**

Refer to P3.

**H12: 3 times Pb error in 60mins**

**Description:**

Refer to Pb.

**P1: High pressure protection**


**Description:**

The high-pressure error, which is the ODU high-pressure port open circuit and send signal to IDU PCB, then “P1” displays on the IDU PCB, unit will stop running.

**Possible causes:**

- High-pressure switch is not connected well
- ODU PCB fault or high-pressure switch fault.
- The ODU coil is air block or lack of water
- The refrigerant pipe is jammed to cause high pressure
- The refrigerant system is recharged with air or other gas inside, overcharge, etc.

**Procedure:**



ected tightly or not, if not, connect it with controller, then wait for the refrigerant system balance, if the P1 high-pressure switch is normal. If the ODU PCB, if P1 error disappears, that means the high-pressure switch is fault, normally the resistance of the high-pressure switch is 0Ω, always close replace it.

- Check the ODU coil if it is air block in cooling mode, if yes, remove the blocker.
- Check the BPHE is lack of water which can not evaporate the refrigerant in heating mode, make sure the water flow rate is suit the unit according to the specification.
- Check if the refrigerant pipe if high pressure side is jammed or not, if yes, maintain it.
- If all above steps are normal, it may cause by the air or other gas inside the refrigerant system, need to vacuum the system and recharge.



- Check the low-pressure switch is connected tightly or not, if not, reconnect it well.
- When the P2 happen, turn off the unit with controller, then wait for the refrigerant system balance, if the P2 disappears, that means the PCB and high-pressure switch is normal.
- If not, short connect the LP port of PCB, if P2 error disappears, that means the low-pressure switch is fault, replace the high-pressure switch. (Normally the resistance of the low-pressure switch is  $0\Omega$ , always close type), if not, the ODU PCB is damaged, replace it.
- Check the ODU coil if it is air block in heating mode, if yes, remove the blocker.
- Check the BPHE is lack of water which can not evaporate the refrigerant in cooling mode, make sure the water flow rate is suit the unit according to the specification.
- Check the refrigerant is insufficient or not, if yes, charge refrigerant correct according to the nameplate.
- Check the refrigerant pipe is jammed or not, if yes, maintain it.

### P3: Over current protection


**Description:**


The unit will stop while it detects the AC current or DC current is higher than the protection value, which will give “P3” error in the IDU PCB, as for the detail value of protection logic, please refer to section “current protection”.

**Possible causes:**

- Power supply cables do not connect well or voltage is too low
- The power connection of compressor is not firmly
- The high-pressure side pipe is block or medium gas inside the system
- The poor heat exchange of condenser, heating mode check the BPHE, cooling mode check the ODU coil
- The inverter module of ODU PCB damaged
- The compressor is damaged

**Procedure:**





Note:

- (1) AC voltage is coming from the power supply to the ODU PCB, single phase of the AC voltage is 220-240V; DC voltage is the power supply to the compressor from ODU PCB, 1-phase unit of the DC voltage is 310-340V, 3-phase unit of DC voltage is 540-590V.
- (2) In heating mode check water side heat exchanger, water piping, circulator pumps and water flow switch for dirt/blockages. In cooling mode check air side heat exchanger, fan(s) and air outlets for dirt/blockages.

- Check the power supply to the ODU PCB, use the multi-meter to check the AC voltage of ODU “L-N” port, normally is 220-240V AC (380-415V for L1-L2 if 3-phase unit), if not, correct the power supply, otherwise go to next step.
- Check the condensing heat exchanger, if it is in the poor heat exchange position: in cooling mode, check the ODU coil is air block or dirty or in bad ventilation, correct the it; in heating mode, check the BPHE is enough with water, the water pump and water flow switch is working normally or not, or water side is jam or not, correct it; otherwise go to next step.
- Check the piping system is bent/jam, which cause high pressure to cause the over current, if yes, maintain it, otherwise go to next step.
- Check the pressure of the system, if it is mix with medium gas or over charge the refrigerant, if yes, relief and recharge.
- Check the resistance of compressor, U-V-W, each port should be within 20Ω, U-G, V-G, W-G should be MΩ or ∞, if not, the compressor is damaged, replace it; if the resistance is correct, use the multi-meter to check the current of U-V-W of compressor, and check the check item 16, DC current, if the value of check item 16 is not similar to the multi-meter, replace the ODU PCB, otherwise go to the next step.
- If the multi-meter detects the compressor is quite big, while the compressor frequency is not high, that means compressor is damaged, replace the compressor; otherwise go to next step.
- If all above steps are correct, replace the ODU PCB.

### P4: Over-heat protection of compressor discharged temperature


**Description:**


The unit will stop while it detects the discharged temperature is higher than the protection value, which will give “P4” error in the IDU PCB, as for the detail value of protection logic, please refer to section “compressor discharged temperature protection”.

**Possible causes:**

- The discharged temperature sensor is fault
- Lack of refrigerant or medium gas inside the system
- The refrigerant pipe is block
- The poor heat exchange of condenser, heating mode check the BPHE, cooling mode check the ODU coil
- The compressor is damaged
- The ODU PCB is damaged

**Procedure:**





Note:

- (1) The resistance of the sensor can refer to the annex I, resistance table of sensor.
- (2) In heating mode check water side heat exchanger, water piping, circulator pumps and water flow switch for dirt/blockages.  
In cooling mode check air side heat exchanger, fan(s) and air outlets for dirt/blockages.

- Check the connection and resistance of the discharged temperature sensor, if the resistance is not correct, replace the sensor, otherwise go to next step.
- Check the connection and resistance of T-in, Tout, T1, T5 sensors, connect them firmly, if the resistance is not correct, replace it, otherwise go to next step. (The capacity demand is calculated basing on the LWT and setting temperature, so these sensors will affect the compressor frequency in high level even the EWT is high)
- Check the condensing heat exchanger, if it is in the poor heat exchange position: in cooling mode, check the ODU coil is air block or dirty or in bad ventilation, correct the it; in heating mode, check the BPHE is enough with water, the water pump and water flow switch is working normally or not, or water side is jam or not, correct it; otherwise go to next step.
- Check the piping system is bent/jam, if yes, maintain it, otherwise go to next step.
- Check the pressure of the system, if it is mix with medium gas or lack of refrigerant, if yes, relief and recharge or add the refrigerant basing on the volume in nameplate.
- Check the resistance of compressor, U-V-W, each port should be within 20Ω, U-G, V-G, W-G should be MΩ or ∞, if not, the compressor is damaged, replace it; if the resistance is correct, check the check item 16, DC current, if the value of check item 16 is quite big, while the compressor frequency is not high, that means compressor is damaged, replace the compressor; otherwise go to next step.
- If all above steps are correct, running the system, check the SV2 valve, the “CN6” port of ODU PCB before the P4 error, the SV2 should be open once the discharged temperature reach the 100°C, if not, replace the ODU PCB.

## P5: Over-heat protection of condenser temperature


### Description:

The unit will stop while it detects the condensing temperature is higher than the protection value, which will give “P5” error in the IDU PCB, as for the detail value of protection logic, please refer to section “compressor discharged temperature protection”.

### Possible causes:

- The condenser temperature sensor is fault
- The poor heat exchange ODU coil
- The medium gas is inside the system
- The ODU PCB is damaged

### Procedure:



### Note:

- (1) The resistance of the sensor can refer to the annex I, resistance table of sensor.
- (2) In cooling mode check air side heat exchanger, fan(s) and air outlets for dirt/blockages.

- Check the connection and resistance of the condenser temperature sensor, if the resistance is not correct, replace the sensor, otherwise go to next step.
- Check the condensing heat exchanger, if it is in the poor heat exchange position: in cooling mode, check the

ODU coil is air block or dirty or in bad ventilation, correct the it; otherwise go to next step.

- Check the pressure of the system, if it is mix with medium gas, if yes, relief and recharge the refrigerant basing on the volume in nameplate.
- If all above steps are correct, replace the ODU PCB.

## P6: IPM board protection (Inverter module error)


### Description:

The unit will stop while it occurs the IPM board protection, and the IDU PCB will display the “P6” error, in this case, it can use the WUI or IDU PCB to check the detail of the error which is caused the P6. For WUI, please refer to the check item 33, and for IDU PCB, refer to the check item 23.

### Possible causes:

- The ODU PCB damaged
- The power supply is not correct
- The heat exchange condition is poor
- Fan motor or compressor damaged

### Procedure:




- Refer to the detail reason of P6 error.

### L0: IPM or IGBT over current

**Check step:**

- Use the multi-meter to check the power supply, the AC voltage between L-N should be 220-240V (for 3-phase unit, L1/L2/L3-N must test one by one), if not, correct the power supply; if yes, go to next step;
- Use the multi-meter to check the DC voltage in below port in red ring, normally it should be DC 310-380V, if not, replace the ODU PCB, if yes, go to next step; (For this step, it can also check this DC voltage through the checked parameter of IDU PCB, item 18, 310-380V for single phase, 5410-590V for 3-phase.)




- It may cause by the refrigerant system issue, refer to P3 and P9.

**L1/L3/L7/L8/LA/Lb/Ld: lack of phase/ DC voltage is too low to protect/ PFC fault/ DC voltage is too high to protect /PWM synchronization fault/ MCE fault/ EEPROM data is wrong**

**Check step:**

- Use the multi-meter to check the power supply, the AC voltage between L-N should be 220-240V (for 3-phase unit, L1/L2/L3-N must test one by one), if not, correct the power supply; if yes, go to next step;
- Use the multi-meter to check the DC voltage in below port in red ring, normally it should be DC 310-380V, if not, replace the ODU PCB. (For this step, it can also check this DC voltage through the checked parameter of IDU PCB, item 18, 310-380V for single phase, 5410-590V for 3-phase.)




- If all above steps are correct, replace the ODU PCB.

## L2/L9/Lc/LE: Compressor losing speed fault/Compressor zero speed fault/Compressor over current protection/Compressor fail to start

### Check step:

- Use the multi-meter to check the power supply, the AC voltage between L-N should be 220-240V (for 3-phase unit, L1/L2/L3-N must test one by one), if not, correct the power supply; if yes, go to next step;
- Use the multi-meter to check the DC voltage in below port in red ring, normally it should be DC 310-380V, if not, replace the ODU PCB. (For this step, it can also check this DC voltage through the checked parameter of IDU PCB, item 18, 310-380V for single phase, 5410-590V for 3-phase.)




- Check the condensing heat exchanger, if it is in the poor heat exchange position: in cooling mode, check the ODU coil is air block or dirty or in bad ventilation, correct the it; in heating mode, check the BPHE is enough with water, the water pump and water flow switch is working normally or not, or water side is jam or not, correct it; otherwise go to next step.
- Check the piping system is bent/jam, which cause high pressure to cause the over current, if yes, maintain it, otherwise go to next step.
- Check the pressure of the system, if it is mix with medium gas or over charge the refrigerant, if yes, relief and recharge.
- Check the “UVW” connection of the compressor is correct sequency or not, if not, correct it; if it is, go to next step.
- Use the multi-meter to check the current of U-V-W of compressor, each line of current should be similar, otherwise the “UVW” may lack of sequency, replace the ODU PCB.
- Check the resistance of compressor, U-V-W, each port should be within 20Ω, U-G, V-G, W-G should be MΩ or ∞, if not, the compressor is damaged, replace it; if the resistance is correct, go to the next step.
- If the multi-meter detects the compressor is quite big, while the compressor frequency is not high, that means compressor is damaged, replace the compressor.

**L4/L5/L6/LF: Fan motor over current protection/ Fan motor lack of phase/ Fan motor zero speed fault/ Fan motor losing speed fault**

**Check step:**

- Use the multi-meter to check the power supply, the AC voltage between L-N should be 220-240V (for 3-phase unit, L1/L2/L3-N must test one by one), if not, correct the power supply; if yes, go to next step;
- Use the multi-meter to check the DC voltage in below port in red ring, normally it should be DC 310-380V, if not, replace the ODU PCB. (For this step, it can also check this DC voltage through the checked parameter of IDU PCB, item 18, 310-380V for single phase, 5410-590V for 3-phase.)



- If the voltage is correct, refer to the P9.

**P9: DC motor protection (DC motor or DC motor module error)**


**Description:**

The unit will stop while the unit happen with “P9” error, which is the DC motor protection, and the IDU PCB would display “P9” error.

**Possible causes:**


- The damage of DC motor
- The damage of DC Motor module
- The damage of ODU PCB
- The heat exchange condition is poor

**Procedure:**




- Use the multi-meter to check the power supply, the AC voltage between L-N should be 220-240V (for 3-phase unit, L1/L2/L3-N must test one by one), if not, correct the power supply; if yes, go to next step;

- Use the multi-meter to check the DC voltage in below port in red ring, normally it should be DC 310-380V, if not, replace the ODU PCB. (For this step, it can also check this DC voltage through the checked parameter of IDU PCB, item 18, 310-380V for single phase, 5410-590V for 3-phase.)




- Check the condensing heat exchanger, if it is in the poor heat exchange position: in cooling mode, check the ODU coil is air block or dirty or in bad ventilation, correct the it; in heating mode, check the BPHE is enough with water, the water pump and water flow switch is working normally or not, or water side is jam or not, correct it; otherwise go to next step.
- Check the motor if it is blocked or not, if it is, correct it; otherwise go to next step.
- For single fan unit, if above the step are correct, replace the ODU PCB, if it still not solved, replace the motor.
- For double fan unit, if the above the correct, please follow the below steps.
- ❖ Check the DC voltage in below ports in red on the ODU PCB:



There are four ports from left to right: GND/+15V/control signal/feedback signal, if the +15V is not correct, replace the ODU PCB.

The voltage between GND-control signal is DC 0-5V, and when unit is on, it should be around 2.5V which is fluctuant, when the unit is off, it should be 0V, if not, replace the ODU PCB, otherwise go to next step.

- ❖ Check the connection cables between ODU PCB and fan motor driven board, if they are not connected well, re-connect it, otherwise go to next step.
- ❖ Check the DC voltage of these ports in the fan motor driven board



For each port, there are five ports from left to right: GND/+15V/control signal/feedback signal, if the +15V is not correct, replace the fan motor driven board.

The voltage between GND-control signal is DC 0-5V, and when unit is on, it should be around 2.5V which is fluctuant, when the unit is off, it should be 0V, if not, replace the driven board, otherwise go to next step.

- ❖ If all above steps are correct, replace the fan motor.



## P11: T2B refrigerant temperature of BPHE over-low protection


### Description:

The unit will stop while the unit detects the T2B refrigerant temperature is low (below  $-10^{\circ}\text{C}$  while the compressor is off; below  $-5^{\circ}\text{C}$  while the compressor is running) in cooling mode, and the IDU PCB will display “P11”. It is used to protect the BPHE against the ice frozen.

### Possible causes:

- The damage of the T2B sensor
- The damage of IDU PCB
- The heat exchange condition is poor
- Lack of refrigerant

### Procedure:



- Check the T2B sensor is connected firmly or not, if not, reconnect it well, otherwise go to next step.
- Take out the T2B sensor, and then use the multi-meter to detect the resistance of the T2B to check if it normal or not. If not, replace the sensor, otherwise go to next step. (Normally it is 5K at  $25^{\circ}\text{C}$ , refer to the annex I for detail of the resistance table.)
- Check the system is water flow rate or not, it can check the water flow rate via WUI according to the check item 7, if yes, please rectify the water flow, otherwise go to the next step.

- Check the system is lack of refrigerant or leakage or not, if yes, repair it and charge the refrigerant according the nameplate, otherwise go to the next step.
- If all the above steps are correct, replace the IDU PCB.

**Pb : IPM temperature over-heat protection**


**Description:**

The unit will stop while the unit detects the IPM temperature is higher than 93°C, and the IDU PCB will display “Pb”.

**Possible causes:**

- The poor heat escape of IPM board
- The damage of ODU PCB

**Procedure:**



- Check the heat escape sink of IPM board is smear with silicone grease smoothly, if not, smear the silicone smoothly, otherwise go to the next step.
- Check the refrigerant cooling pipe is fixed well with the heat escape sink, if not, fix it well, otherwise go to the next step.
- If above steps are correct, replace the ODU PCB.

## 6. Components maintaining

### 6.1.Tooling presentation

Here attached the maintaining tooling which will be used for main components service, the pictures below are just for reference, they may be different in local market. Please choose the correct tools according to the local market to service.




Table 6-1-1

Name	Picture	Name	Picture
Screw		Pliers	
Spanner		Hexagonal socket wrench	
Cutter		Welding device	
Piping cutter		Vacuum pump	
Pressure gage		Flaring tool	





## 6.2.Maintaining step



Around the heat pump, it has two body size that 4-10kW is single fan and 12-16kW is double fan. Here attached the guidance for the main components service of these two body.

### ▪ Fan blade

Steps	4-10kW	12-16kW
1	<ul style="list-style-type: none"> <li>❖ Remove the 4 screws with the screw, then take out the fan grill</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Remove the 4 screws with the screw, then take out the fan grill</li> </ul> 
2	<ul style="list-style-type: none"> <li>❖ Hold the fan blade and release the nut with spanner, remove the nut and gasket,</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Hold the fan blade and release the nut with spanner, remove the nut and gasket</li> </ul> 
3	<ul style="list-style-type: none"> <li>❖ Hold the fan blade with hands to take it out careful to avoid breaking</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Hold the fan blade with hands to take it out careful to avoid breaking</li> </ul> 






▪ Fan motor

Steps	4-10kW	12-16kW
1	<ul style="list-style-type: none"> <li>❖ Remove the 4 screws with the screw, then take out the fan grill</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Remove the 4 screws with the screw, then take out the fan grill</li> </ul> 
2	<ul style="list-style-type: none"> <li>❖ Hold the fan blade and release the nut with spanner, remove the nut and gasket,</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Hold the fan blade and release the nut with spanner, remove the nut and gasket</li> </ul> 
3	<ul style="list-style-type: none"> <li>❖ Hold the fan blade with hands to take it out careful to avoid breaking</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Hold the fan blade with hands to take it out careful to avoid breaking</li> </ul> 
4	<ul style="list-style-type: none"> <li>❖ Lose the fixing clamp, and take out the motor cable connector from PCB</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the screw to lose the screws of top panel, and then remove the top panel</li> </ul> 
5	<ul style="list-style-type: none"> <li>❖ Use the hexagonal socket wrench to release the 4 nuts,</li> </ul>	<ul style="list-style-type: none"> <li>❖ Use the pliers to take out the motor cable from fan</li> </ul>


	<p>and take off the gaskets</p> 	<p>motor module board (this board is in the rear side), and lose the clamp</p> 
6	<p>❖ Hold the motor with hands, then take it out</p> 	<p>❖ Use the hexagonal socket wrench to release the 4 nuts, and take off the gaskets</p> 
7		<p>❖ Hold the motor with hands, then take it out</p> 

▪ **Water pump**

Steps	4-10kW	12-16kW
1	<p>❖ Remove the screws of right panel</p> 	<p>❖ Remove the screws of the right panel</p> 
2	<p>❖ Hold the right panel and take it out</p>	<p>❖ Hold the right panel and take it out</p>


		
3	<p>❖ Use the spanner to lose the 2 nuts of the water pump</p> 	<p>❖ Use the spanner to lose the 2 nuts of the water pump</p> 
4	<p>❖ Take out the water pump with hands after full release the nuts, please not the water flow direction symbol of the pump, it should be same as water flow</p> 	<p>❖ Take out the water pump with hands after full release the nuts, please not the water flow direction symbol of the pump, it should be same as water flow</p> 
5	<p>❖ Take out the cable out from the pump, then take the water pump full out from the unit</p> 	<p>❖ Take out the cable out from the pump, then take the water pump full out from the unit</p> 

▪ **Water flow switch**



Steps	4-10kW	12-16kW
1	<ul style="list-style-type: none"> <li>❖ Remove the screws of right panel</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Remove the screws of the right panel</li> </ul> 
2	<ul style="list-style-type: none"> <li>❖ Hold the right panel and take it out</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Hold the right panel and take it out</li> </ul> 
3	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of the top panel, and take out the top panel</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the spanner to lose the water flow switch, and then take it out from the water pipe (please not the sealed gasket should keep to seal)</li> </ul> 
4	<ul style="list-style-type: none"> <li>❖ Use the spanner to lose the water flow switch, and then take it out from the water pipe (please not the sealed gasket should keep to seal)</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the screw to lose the water flow switch signal from PCB</li> </ul> 




5

- ❖ Use the screw to lose the water flow switch signal from PCB












▪ **Standard electronic heater**

Steps	4-10kW	12-16kW
1	<ul style="list-style-type: none"> <li>❖ Remove the screws of right panel</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Remove the screws of the right panel</li> </ul> 
2	<ul style="list-style-type: none"> <li>❖ Hold the right panel and take it out</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Hold the right panel and take it out</li> </ul> 
3	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of the top panel, and take out the top panel</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of the top panel, and take out the top panel</li> </ul> 
4	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of right-back panel, and release the electronic heater power cable from terminal</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of right-back panel, and release the electronic heater power cable from terminal</li> </ul> 
5	<ul style="list-style-type: none"> <li>❖ Use the spanner to lose the water pipe connection nuts</li> </ul>	<ul style="list-style-type: none"> <li>❖ Use the spanner to lose the water pipe connection nuts</li> </ul>




		
6	<ul style="list-style-type: none"> <li>❖ After release the water pipe nuts, remove the water pipe (Please take care about the sealed material which is needful)</li> </ul> 	<ul style="list-style-type: none"> <li>❖ After release the water pipe nuts, remove the water pipe (Please take care about the sealed material which is needful)</li> </ul> 
7	<ul style="list-style-type: none"> <li>❖ Use the screws to release the screws of electronic heater component from the back plate, then take it out.</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the screws to release the screws of electronic heater component from the back plate, then take it out.</li> </ul> 





▪ Brazed plate heat exchanger

Steps	4-10kW	12-16kW
1	<p>❖ Remove the screws of right panel</p> 	<p>❖ Remove the screws of the right panel</p> 
2	<p>❖ Hold the right panel and take it out</p> 	<p>❖ Hold the right panel and take it out</p> 
3	<p>❖ Use the screw to release the screws of the top panel, and take out the top panel</p> 	<p>❖ Use the screw to release the screws of the top panel, and take out the top panel</p> 
4	<p>❖ Use the screw to release the screws of front septum, and take it out</p> 	<p>❖ Use the screw to release the screws of right-back panel and take it out</p> 
5	<p>❖ Use the spanner to lose the water pipe connection nuts of BPHE</p>	<p>❖ Use the spanner to lose the water pipe connection nuts of BPHE</p>


		
6	<p>❖ After release the water pipe nuts, use the welding tool to weld the refrigerant pipe of BPHE out (Please note that it must release the refrigerant before welding)</p> 	<p>❖ After release the water pipe nuts, use the welding tool to weld the refrigerant pipe of BPHE out (Please note that it must release the refrigerant before welding)</p> 
7	<p>❖ Use the screws to release the 4 screws of BPHE holder, then take it out.</p> 	<p>❖ Use the hexagonal socket wrench to release the 4 hexagonal screws of BPHE holder, then take it out.</p> 





▪ 4-way valve

Steps	4-10kW	12-16kW
1	<ul style="list-style-type: none"> <li>❖ Remove the screws of right panel</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Remove the screws of the right panel</li> </ul> 
2	<ul style="list-style-type: none"> <li>❖ Hold the right panel and take it out</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Hold the right panel and take it out</li> </ul> 
3	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of the top panel, and take out the top panel</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of the mid-front panel, and take out the panel</li> </ul> 
4	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of mid-front panel, and take it out</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of coil of 4-way valve panel and take it out</li> </ul> 
5	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of refrigerant cool sink, and ODU electronic box, then take the ODU electronic out</li> </ul>	<ul style="list-style-type: none"> <li>❖ Use the welding tool to weld the 4-way valve off (Before welding, it must full release the refrigerant out, and during the welding, it must cool the 4-way valve</li> </ul>




		<p>body efficiently with wet fabric)</p>  <p>Cool the body</p>
6	<p>❖ Use the screw to release the screws of coil of 4-way valve panel and take it out</p> 	
7	<p>❖ Use the welding tool to weld the 4-way valve off (Before welding, it must full release the refrigerant out, and during the welding, it must cool the 4-way valve body efficiently with wet fabric)</p>  <p>Cool the body</p>	







▪ **Electronic expansion valve**


Steps	4-10kW	12-16kW
1	<ul style="list-style-type: none"> <li>❖ Remove the screws of right panel</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Remove the screws of the right panel</li> </ul> 
2	<ul style="list-style-type: none"> <li>❖ Hold the right panel and take it out</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Hold the right panel and take it out</li> </ul> 
3	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of mid-front panel, and take it out</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of the mid-front panel, and take out the panel</li> </ul> 
4	<ul style="list-style-type: none"> <li>❖ Remove the coil of electronic expansion valve, and take it out</li> </ul>	<ul style="list-style-type: none"> <li>❖ Remove the coil of electronic expansion valve, and take it out</li> </ul>

		
5	<p>❖ Use the welding tool to weld the electronic expansion valve off (Before welding, it must full release the refrigerant out, and during the welding, it must cool the 4-way valve body efficiently with wet fabric)</p>  <p>Cool the body</p>	<p>❖ Use the welding tool to weld the electronic expansion valve off (Before welding, it must full release the refrigerant out, and during the welding, it must cool the 4-way valve body efficiently with wet fabric)</p> 

▪ Compressor

Steps	4-10kW	12-16kW
1	<ul style="list-style-type: none"> <li>❖ Remove the screws of right panel</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Remove the screws of the right panel</li> </ul> 
2	<ul style="list-style-type: none"> <li>❖ Hold the right panel and take it out</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Hold the right panel and take it out</li> </ul> 
3	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of the top panel, and take out the top panel</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of the mid-front panel, and take out the panel</li> </ul> 
4	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of mid-front panel, and take it out</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Remove the top cover of the insulation of compressor, and take it out</li> </ul> 
5	<ul style="list-style-type: none"> <li>❖ Use the screw to release the screws of refrigerant cool sink, and ODU electronic box, then take the ODU electronic out</li> </ul>	<ul style="list-style-type: none"> <li>❖ use the spanner to release the screw of the terminal cover of compressor, then remove it, after that, use the</li> </ul>

		<p>pliers to take cable out</p> 
6	<ul style="list-style-type: none"> <li>❖ Remove the top cover of the insulation of compressor, and use the spanner to release the screw of the terminal cover of compressor, then remove it, after that, use the pliers to take cable out</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the welding tool to weld the suction pipe and discharged pipe of compressor (Before welding, it must full release the refrigerant out)</li> </ul> 
7	<ul style="list-style-type: none"> <li>❖ Use the welding tool to weld the suction pipe and discharged pipe of compressor (Before welding, it must full release the refrigerant out)</li> </ul> 	<ul style="list-style-type: none"> <li>❖ Use the spanner to release the 3 nuts of compressor, then take the compressor out</li> </ul> 
8	<ul style="list-style-type: none"> <li>❖ Use the spanner to release the 3 nuts of compressor, then take the compressor out</li> </ul>	



## 7. WUI operation

### 7.1.Presentation

This WUI (wall-mounted user interface) is used to control the operation of unit and configuration of the system. It can also be used to check the system running parameter and display the status of system via the LCD screen.

The WUI communicates with the IDU (Indoor unit) board with certain protocol, and detect the communication status at real time. IDU board will give communication fault alarm once it loses communication. But it will not give alarm if you did not connect the WUI to the IDU board when power on the system. So please note that if the WUI is not necessary, please do not connect it before power on the system.

The WUI will off its screen for energy saving without pressing for 35s (except the technical parameter configuration), and will wake up once you press any button.



Application of WUI:

- 1 Power supply: Take power supply from IDU board (12V power supply);
- 2 Working temperature range: -30°C~50°C;
- 3 Working humidity range: RH10%~95%


WUI can be installed inside your home or on the unit itself.

This manual provides guidelines on how to use this interface effectively.

If you have any questions regarding the display and its configuration, please contact your installer for more information.

### a) Interface introduction

- Button overview



Definition	Description
1 Mode button	Used to change the running mode
2 Electric heater button	Used to manual on/off the DHW EHs manually
3 Up button	Used to change the value of parameter or turn page during system configuration or commissioning
4 Down button	Used to change the value of parameter or turn page during system configuration or commissioning
5 Setting button	Used to set user parameter configuration or technical parameter configuration
6 Confirm button	Used to confirm the current setting
7 ON/OFF button	Used to turn on/off the unit
8 Query button	Used to query the operation parameter or configuration parameter



- Icon overview

	Non-operating cooling mode		Non-operating heating mode		Non-operating DHW mode
	Operating cooling mode		Operating heating mode		Operating DHW mode
	Anti-frozen protection		Main water loop EHs		DHW EHs
	External heat source (boiler)		Weekly timer		Clock
	Timer on		Timer off		Alarm
	Air purge mode		OTA (water setpoint control)		IAT (air setpoint control)
	LWT/time display (hour)/alarm		DHW temp./time display (minute)		IAT/OAT (OAT is reserved)
<b>SUN MON TUE WED THU FRI SAT</b>	Days of week		Constant light: Eco mode Flash: Away mode		

Please note that the home screen display may vary depending on unit configuration and screen setting.

## b) Button introduction

This WUI has 8 buttons for the setpoint control, configuration, parameter check, etc. Detail of each button is as below table:

	<ul style="list-style-type: none"> <li>Press this button to turn on and turn off the unit.</li> </ul>
<p>ON/OFF</p>	
	<ul style="list-style-type: none"> <li>Press this button to confirm the setting to exit interface of parameter setting or query.</li> </ul>
<p>Confirm</p>	
	<ul style="list-style-type: none"> <li>Press this button to change the mode: cooling-heating-cooling.</li> <li>Press and hold this button to active the anti-legionella mode manually.</li> </ul>
<p>Mode</p>	
	<ul style="list-style-type: none"> <li>Press this button to check the configuration and running parameters.</li> <li>Refer to the section 3, parameter and status check for details.</li> </ul>
<p>Query</p>	
	<ul style="list-style-type: none"> <li>While operating heating mode, press this button to activate/deactivate the main water loop EHs manually.</li> <li>While operating the DHW mode, press this button to activate/deactivate the DHW EHs manually.</li> <li>Press and hold this button to start the force-defrosting, and WUI will display “dF” for 5s.</li> </ul>
<p>EHs</p>	
	<ol style="list-style-type: none"> <li>Temperature setting <ul style="list-style-type: none"> <li>While in standby mode, first time press this button to change the setting value of LWT, press the confirm button or wait for 5s without pressing any button to DHW temperature setting.</li> <li>While operating cooling/heating mode, first time press this button to change the setting value of LWT, press the confirm button or wait for 5s without pressing any button to DHW temperature setting.</li> <li>While operating DHW mode, first time press this button to change the setting temperature of DHW, press the confirm button or wait for 5s without pressing any button to setting value of LWT.</li> </ul> </li> </ol>
<p>Up</p>	
	<ol style="list-style-type: none"> <li>Time correction and timer setting <ul style="list-style-type: none"> <li>Refer to details of configuration.</li> </ul> </li> </ol>
<p>Down</p>	
	<ul style="list-style-type: none"> <li>User parameter configuration, please refer to configuration section.</li> <li>Technical parameter configuration, please refer to configuration section.</li> </ul>
<p>Setting</p>	

## 7.2. User operation

### a) Clock setting

Before using the WUI, it is necessary to set the time and day of the controller. Please follow below steps to set the correct clock:

- 1 Press the “setting” button, then press “confirm” button to enter day setting ;the day is flashing at this moment.




- 2 Then press “up” or “down” button to change the day if necessary;




- 3 After day setting, press the “confirm” button or hour setting, the hour is flashing at this moment.



- 4 Then press “up” or “down” button to set the correct time in hour;



5 After hour setting, press the “confirm” button to enter minute setting, the minute is flashing at this moment.



6 Then press “up” or “down” button to set the correct time in minute;



7 Press “confirm” button to confirm and exit ( ) setting. You can also press “setting” button to go to next parameter. (Refer the user parameter configuration for the full parameters setting)

**Example: Friday, 3:05:31**



**b) ON-OFF setting**

Press this button to turn on and turn off the unit. And the mode icon is lighting at this moment.



**c) Mode setting**

Press this button to change the mode: cooling-heating-cooling.



**Example:**



Mode	Cooling	Mode heating	Heating
Occupancy	Home	Occupancy	Home
Temp. control	Water setpoint control	Temp. control	Water setpoint control
Setpoint of LWT	17°C	Setpoint of LWT	18°C
Setpoint of DHW	25°C	Setpoint of DHW	25°C

#### d) Current setpoint setting

Here are two setpoint control: (Refer to the technical parameter configuration, item 1 for details setting)

- Water setpoint control; the unit is controlled by water setpoint;
- Air setpoint control: the unit is controlled by the air setpoint, and it requests to install the WUI into the room. There is an IAT sensor built inside the WUI to detect the room temperature.


#### Here are the steps to change setting of water setpoint control:

1 While in standby mode or operating cooling/heating mode:

- First time press “up” or “down” button to change the setting value of LWT;




- Then press the confirm button or wait for 5s without pressing any button to DHW temperature setting. Then press “up” or “down” button to change the setting value of DHW.




2 While operating DHW mode:

- First time press “up” or “down” button to change the setting temperature of DHW;



- Press the confirm button or wait for 5s without pressing any button to setting value of LWT. Then press “up” or “down” button to change the setting value of LWT.







**Here are the steps to change setting of air setpoint control:**

1 While in standby mode or operating cooling/heating mode:

- i. First time press “up” or “down” button to change the setting value of air setpoint;




- ii. Then press the confirm button or wait for 5s without pressing any button to DHW temperature setting. Then press “up” or “down” button to change the setting value of DHW.



2 While operating DHW mode:

- i. First time press “up” or “down” button to change the setting temperature of DHW;



- ii. press the confirm button or wait for 5s without pressing any button to setting value of LWT. Then press “up” or “down” button to change the setting value of air setpoint.





### e) Home/away/eco setting

To optimize energy efficiency of the building, you can select the occupancy mode manually according to following steps. Each occupancy mode is associated with a pre-defined temperature range.

- 1 Press the “setting” button to item 5: Occupancy mode select



- 2 Press “up” or “down” button to change the value. (0-Home; 1-Eco; 2-Away)



- 3 Then press “confirm” button to confirm and exit user setting or you can also press “setting” button to go to next item.

(Refer to the user parameter configuration for the full parameters setting)

### Example: Eco mode:




This coin is lighting after set the eco mode.




**f) DHW schedule setting**

This schedule is used to set the operating of DHW mode automatically according to time schedule. Please follow below steps to set the DHW schedule:


- 1 Press the “setting” button to item 1: DHW schedule setting



- 2 Press and hold the “confirm” button, the icon “on” will be flashing, then press the “confirm” button to confirm, the icon “on” will be constant lighting;




- 3 Press and hold the “down” button to enter day setting, then press “up” or “down” button to select the day, press the “confirm” button to confirm day setting, after that, the icon of that day will be constant lighting;



- 4 Press and hold the “confirm” button to enter hour setting, then press “up” or “down” button to select the time in hour, press the “confirm” button to confirm;



- 5 Press and hold “down” button to enter minute setting, then press “up” or “down” button to select the time in minute, press the “confirm” button to confirm;



- 6 Press and hold “down” button to set the timer off, then press the “down” button to enter hour setting, then press “up” or “down” button to select the time in hour, press the “confirm” button to confirm;



- 7 Press and hold “down” button to enter minute setting, then press “up” or “down” button to select the time in minute, press the “confirm” button to confirm;



- 8 Press and hold “confirm” button to confirm and exit user setting. You can also press “setting” button to go to next item.

(Refer to the user parameter configuration for the full parameters setting)

**Example:**

The unit will operate the DHW mode at 22:00 from Monday to Friday, and will exit DHW mode automatically at 6:00 from Tuesday to Saturday.

Schedule of DHW mode							
Day	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday
	√	√	√	√	√	×	×
Time on	22:00	22:00	22:00	22:00	22:00	22:00	22:00
Time off	6:00	6:00	6:00	6:00	6:00	6:00	6:00

**g) WUI button lock setting**

Used to lock the button of WUI in case of touching by mistake; and double press “setting” button to unlock.

- 1 Press the “setting” button to item 9: WUI button lock



- 2 Press the “up” or “down” button to set the value (0-unlock; 1-lock)



- 3 Then press “confirm”  to confirm and exit user setting or you can also press “setting” button to go to next item.

(Refer to the user parameter configuration for the full parameters setting)

### 7.3.Configuration

This WUI can be used to configurate the system setting during the installation and operation. Here enclosed two configuration sections: user parameter configuration and technical parameter configuration, please check the details in a) & b).

#### a) User parameter configuration

Press the “setting” button to go into the user parameter configuration interface, and press this button to page down the setting item from 0-9 as circuit. Used the “up” or “down” button to change the value of each item.

Details of the user parameter configuration table is as below: (The No. in below table will be displayed in the left LED tube except “0”)

No.	Item	Description
0	Clock setting	<ol style="list-style-type: none"> <li>1 Press the “setting” button, then press “confirm” button to enter day setting, then press “up” or “down” button to change the day if necessary;</li> <li>2 After day setting, press the “confirm” button to enter hour setting, press “up” or “down” button to set the correct time in hour;</li> <li>3 After hour setting, press the “confirm” button to enter minute setting, press “up” or “down” button to set the correct time in minute;</li> <li>4 Press “confirm” button to confirm and exit clock setting. You can also press “setting” button to go to next parameter.</li> </ol>
1	Schedule of DHW	<ol style="list-style-type: none"> <li>1 Press and hold the “confirm” button, the icon “on” will be flashing, then press the “confirm” button to confirm, the icon “on” will be constant lighting;</li> <li>2 Press and hold the “down” button to enter day setting, then press “up” or “down” button to select the day, press the “confirm” button to confirm day setting, after that, the icon of that day will be constant lighting;</li> <li>3 Press and hold the “down” button to enter hour setting, then press “up” or “down” button to select the time in hour, press the “confirm” button to confirm;</li> <li>4 Press and hold “down” button to enter minute setting, then press “up” or “down” button to select the time in minute, press the “confirm” button to confirm;</li> <li>5 Press and hold “down” button to set the timer off, then press the “down” button to enter hour setting, then press “up” or “down” button to select the time in hour, press the “confirm” button to confirm;</li> <li>6 Press and hold “down” button to enter minute setting, then press “up” or “down” button to select the time in minute, press the “confirm” button to confirm;</li> <li>7 Press and hold “confirm” button to confirm and exit user setting. You can also press “setting” button to go to next item.</li> </ol>
2	Power memory setting	<p>This is used to record the setting once power is shutdown, and system will recovery the previous status once power come back</p> <ol style="list-style-type: none"> <li>1 Press “up” or “down” button to set the value;</li> </ol> <p>0- Without power memory; 1- With power memory (default)</p>
3	WIFI statue	Reserved
4	Air purge setting	<ol style="list-style-type: none"> <li>1 Press the “up” or “down” button to set the value;</li> </ol> <p>0- Not start air purge mode 1- Start air purge mode</p> <p>If choose 0, then press the “setting” button to go to next item; If choose 1, then press the “confirm” button to exit the setting and unit will start the air purge mode; during the air purge mode, WUI will be displayed “PA”, and only the “ON/OFF” button are valid to exit this mode.</p>
5	Occupancy mode setting	<ol style="list-style-type: none"> <li>1 Press “up” or “down” button to set the value;</li> <li>2 Then press “confirm” button to confirm and exit user setting or you can also press “setting” button to go to next item.</li> </ol> <p>0- Home</p>

		1- Eco 2- Away
6	Night mode setting	This is used to setting the night mode for low noise during night-time. Press “up” or “down” button to set the value; 0- Without night mode 1- With night mode If choose 0, press “confirm” button to confirm and exit user setting or you can also press “setting” button to go to next item; If choose 1, then follow as below: 1 Press “confirm” button to set the start timer setting, then press “up” or “down” button to set time in hour; 2 Press “confirm” button to enter minute setting, then press “up” or “down” button to set time in minute; 3 Press the “confirm” button to enter the stop timer setting, then press “up” or “down” button to set time in hour; 4 Press “confirm” button to enter minute setting, then press “up” or “down” button to set time in minute; 5 Then press “confirm” button to confirm and exit user setting or you can also press “setting” button to go to next item.
7	Anti-legionella temperature setting	Press the “up” or “down” button to set the value; Temperature range: 60-70°C, default as 60°C.
8	Anti-legionella timer start	1 Press and hold “confirm” button to enter day setting, press “down” button to set the day, then press the “confirm” button to confirm, after that, the icon of the day will be constant lighting; 2 Press and hold the “down” button to enter hour setting, then press “up” or “down” button to select the time in hour, press the “confirm” button to confirm; 3 Press and hold “down” button to enter minute setting, then press “up” or “down” button to select the time in minute, press the “confirm” button to confirm; 4 Press and hold “confirm” button to confirm and exit user setting or you can also press “setting” button to go to next item.
9	Lock of WUI	Used to lock the button of WUI in order to child touch for mistake; double press the “setting” button to unlock. 1 Press the “up” or “down” button to set the value; 2 Then press “confirm” button to confirm and exit user setting or you can also press “setting” button to go to next item. 0- Without lock 1- With lock

#### b) Technical parameter configuration

Press and hold the “setting” button to go into the technical parameter configuration interface, and press “setting” button to turn down the setting item from 0-22. You can use “up” or “down” button to change the value of each item.

Details of the user parameter configuration table as below:

No.	Item	Description
0	Control setpoint type	0- Water setpoint control 1- Air setpoint control
1	Controller selection	0- WUI (Wired controller) 1- Dry contact
2	Back up function	0- Main water loop EHs + DHW EHs + boiler 1- Main water loop EHs + DHW EHs 2- DHW EHs + boiler 3- Main water loop EHs + boiler 4- DHW EHs only 5- Boiler only

		6- Main water loop EHs only 7- Non back up
3	Climate curve selection	<p>0- Non climate curve 1- Climate curve</p> <p>After set the 1 with climate curve, please follow the below steps:</p> <p>1 After choose 1, enter heating climate setting, press “up” or “down” button to choose the climate curve 1-13, if choose 1-12, press “confirm” button, then go to step ③; if choose 13, press “confirm” button, then go to step ②;</p> <p>2 Customized heating curve value input:</p> <ul style="list-style-type: none"> <li>• Press “up” or “down” to set the value of MinOAT;</li> <li>• Then press “confirm” button to set MaxOAT, press “up” or “down” to set the value of MaxOAT;</li> <li>• Then press “confirm” button to set MinWSP, press “up” or “down” to set the value of MinWSP;</li> <li>• Then press “confirm” button to set MaxWSP, press “up” or “down” to set the value of MaxWSP;</li> <li>• Press the “confirm” button to step ③;</li> </ul> <p>3 Press “up” or “down” button to set the heating climate offset from -5~5°C, default as 0°C; then press “confirm” button to go to step ④;</p> <p>4 Enter cooling climate setting, press “up” or “down” button to choose the climate curve 1-3, if choose 1-2, press “confirm” button, then go to step ⑥; if choose 3, press “confirm” button to go to step ⑤;</p> <p>5 Customized heating curve value input:</p> <ul style="list-style-type: none"> <li>• Press “up” or “down” to set the value of MinOAT;</li> <li>• Then press “confirm” button to set MaxOAT, press “up” or “down” to set the value of MaxOAT;</li> <li>• Then press “confirm” button to set MinWSP, press “up” or “down” to set the value of MinWSP;</li> <li>• Then press “confirm” button to set MaxWSP, press “up” or “down” to set the value of MaxWSP;</li> <li>• Press the “confirm” button to go to step ⑥;</li> </ul> <p>6 Press the “up” or “down” button to set the heating climate offset from -5~5°C, default as 0°C; then press “confirm” button to confirm and exit or “setting” button to go to next item</p>
4	Capacity test setting	Reserved
5	3-way valve type select	0- Normal open 1- Normal closed
6	DI5	0- Disable 1- Power limitation (night mode)
7	DI6	2- Load-shed 3- DHW request
8	DI7	4- Anti-legionella request 5- DHW priority
9	DI8	
10	DO5	9- Disable 10- Unit in alarm 11- Unit in standby 12- Unit running
11	DO7	13- Unit in cooling 14- Unit in heating 15- Unit in DHW 16- Unit in defrost 17- Unit controlled by Modbus

12	DO8	
13	Eco mode cooling setpoint offset	If choose air setpoint, it is air setpoint offset, otherwise is water setpoint offset 0~10°C, default as 2°C
14	Away mode cooling setpoint offset	If choose air setpoint, it is air setpoint offset, otherwise is water setpoint offset 0~10°C, default as 4°C
15	Eco mode heating setpoint offset	If choose air setpoint, it is air setpoint offset, otherwise is water setpoint offset -20~0°C, default as -2°C
16	Away mode heating setpoint offset	If choose air setpoint, it is air setpoint offset, otherwise is water setpoint offset -20~0°C, default as -4°C
17	Eco mode DHW setpoint offset	-10~0°C, default as -5°C
18	Minimum OAT for heating	-26~10°C, default as -26°C
19	Booster OAT Threshold	-10~0°C, default as -5°C
20	Heat pump warmup time	0~120min, default 60min
21	Booster Delta temperature	1~20°C, default 10°C
22	Second zone setting	Reserved

Note: All the setting will only be changed by reset, never be cleaned by repower.

#### 7.4.Parameter and statue checking

This WUI can be used to check the system status and running parameter. Press the “query” button to go into the parameter query interface, and press “confirm” button or without pressing any button for more than 10s to exit the parameter query interface.

After going into query interface, press “up” or “down” button to check the parameters or status as follow table:

No.	Definition	Description
1	Setting temp.: Ts1	Display Ts1 during standby/cool/heat mode
2	Setting temp.: Ts2	Display Ts2 during DHW mode
3	Setting temp.: Ts3	Display Ts3 when it chooses the air setpoint control
4	Capacity of unit	HP*10, example: 10 means that unit is 1HP capacity
5	Target frequency	
6	Running frequency	
7	Water flow rate	m <sup>3</sup> /h, feedback from inverter water pump
8	Capacity output	=1.163* (water flow rate) * [Tw out – Tw in] (kW)
9	T3 value	ODU coil temp.
10	T4 value	OAT
11	TP value	Discharged temp.
12	T7 value	Temp. of refrigerant for PCB cool
13	EVX opening degree	Actually value
14	ODU fan motor speed	
15	AC current	
16	AC voltage	
17	IPM temp. (T9)	Compressor module temp.
18	Limitation reason of compressor frequency	0: no limitation; 1: T3B temp. limitation (reserved); 2: OAT limitation; 4: Discharged temp. limitation; 8: Voltage limitation 16: Current limitation 32: IPM temp' limitation 64: Night mode limitation 128: LWT limitation If occur multi limitation, display value=sum of all limitation value
19	Limitation reason of compressor frequency	0: no limitation; 1: Limitation of different value between EWT&LWT
20	Tw_in value	EWT
21	Tw_out value	LWT of BPHE
22	T1 value	LWT of unit (after the EHs inside the unit)
23	T6 value	IAT, the sensor built inside the wired controller
24	T5 value	DHW value
25	Tw-2 value	Second zone EWT value when set this function (reserved)
26	T1B value	External heat source (boiler) LWT value
27	Capacity demand	
28	Inv. Pump speed	
29	Last alarm	
30	Penult alarm	
31	Antepenultimate alarm	
32	Current protection	P0-P3: check the detail in alarm table
33	Detail of P6 alarm in function board	L-: no alarm; L0: IPM or IGBT over current; L1: lack of phase L2: Compressor losing speed fault; L3: DC voltage is too low to protect L4: Fan motor over current protection

		L5: Fan motor lack of phase; L6: Fan motor zero speed fault L7: PFC fault L8: DC voltage is too high to protect L9: Compressor zero speed fault LA: PWM synchronization fault Lb: MCE fault Lc: Compressor over current protection Ld: EEPROM data is wrong LE: Compressor fail to start; LF: fan motor losing speed fault
34	SV2 statue of water loop	2-way valve which is used to change the cool/heat water between fan coil and radiator (OFF-0; ON-1)
35	SV3 statue of water loop	DHW 3-way valve
36	Main water loop EHs statue	Standard equip with one EH, another two are field supply (OFF-0; ON-1)
37	DHW EHs	OFF-0; ON-1
38	External heat source statue	OFF-0; ON-1
39	P o	External main water loop pump (OFF-0; ON-1)
40	P p	Second zone water loop pump (OFF-0; ON-1)
41	P m	External heat source water loop pump (OFF-0; ON-1)
42	Anti-frozen heater statue	OFF-0; ON-1
43	Chassis heater statue	OFF-0; ON-1
44	Crank heater statue	OFF-0; ON-1
45	SV2 statue of refrigerant system	FCU water loop valve, to cut off water supply to radiator/space heater coil in cool mode (OFF-0; ON-1)

## 7.5. Error code of WUI

This WUI is also worked as the detector to display the alarm of the unit as follow table:

Example: E1



: This icon will be lighting once alarm happen.

Alarm code	Description
E0	Water flow switch fault
E1	Communication fault between IDU board and ODU board
E2	LWT of unit sensor (T1 sensor) fault
E3	Gas refrigerant temp sensor (T2 sensor) fault (reserved)
E4	Liquid refrigerant temp sensor (T2B sensor) fault (reserved)
E5	ODU (module part) alarm
E6	DHW sensor (T7 sensor) fault
E7	LWT sensor (T <sub>in</sub> sensor) fault
E8	LWT of BPHE sensor (T <sub>out</sub> sensor) fault
E9	Communication fault between WUI and function board
EA	Second zone LWT sensor (Tw_2 sensor) fault (Only valid after setting second zone function, reserved)
Eb	External heat source LWT sensor (T1B sensor) fault (Only valid after set the external heat source – boiler)
Ec	Reserved
Ed	Reserved
EE	Reserved
EF	Mode conflict (reserved)
P0	EEPROM fault
P1	Protection of huge different values between EWT and LWT
P2	Protection of lack of water
P3	Protection of abnormal different value between EWT and LWT

Note:

- When it is displayed the E5-ODU alarm, that needs to check the alarm on the IDU PCB for more detail.
- P0-P3 will only be displayed after it occurs 3 times in 1h, and can't resume unless repower the system.

# Annex I

## Resistance table of sensors

❖ Sensor except discharged temperature sensor (5K)

Temp. (°C)	R-Min (KΩ)	R-Std (KΩ)	R-Max (KΩ)	Voltage (V)5V、 4.3K		Temp. (°C) R-Min	R-Min (KΩ)	R-Std (KΩ)	R-Max (KΩ)	Voltage (V)5V、 4.3K	
				up	down					up	down
-30	51.159	52.84	54.521	0.38	<b>4.62</b>	26	4.771	4.821	4.871	2.36	<b>2.64</b>
-29	48.659	50.232	51.805	0.39	<b>4.61</b>	27	4.599	4.649	4.699	2.4	<b>2.6</b>
-28	46.299	47.772	49.248	0.41	<b>4.59</b>	28	4.434	4.485	4.535	2.45	<b>2.55</b>
-27	44.071	45.452	46.832	0.43	<b>4.57</b>	29	4.277	4.327	4.377	2.49	<b>2.51</b>
-26	41.968	43.261	44.554	0.45	<b>4.55</b>	30	4.126	4.176	4.226	2.54	<b>2.46</b>
-25	39.981	41.193	42.405	0.47	<b>4.53</b>	31	3.981	4.031	4.081	2.58	<b>2.42</b>
-24	38.102	39.238	40.375	0.49	<b>4.51</b>	32	3.842	3.892	3.942	2.62	<b>2.38</b>
-23	36.326	37.391	38.457	0.52	<b>4.48</b>	33	3.709	3.759	3.808	2.67	<b>2.34</b>
-22	34.646	35.645	36.645	0.54	<b>4.46</b>	34	3.581	3.631	3.68	2.71	<b>2.29</b>
-21	33.055	33.993	34.931	0.56	<b>4.44</b>	35	3.495	3.508	3.557	2.77	<b>2.23</b>
-20	31.55	32.43	33.31	0.59	<b>4.41</b>	36	3.34	3.389	3.438	2.8	<b>2.2</b>
-19	30.097	30.923	31.748	0.61	<b>4.39</b>	37	3.226	3.275	3.323	2.84	<b>2.16</b>
-18	28.722	29.497	30.271	0.64	<b>4.36</b>	38	3.117	3.165	3.213	2.88	<b>2.12</b>
-17	27.42	28.147	28.873	0.66	<b>4.34</b>	39	3.012	3.06	3.107	2.92	<b>2.08</b>
-16	26.186	26.868	27.55	0.69	<b>4.31</b>	40	2.912	2.959	3.006	2.96	<b>2.04</b>
<b>-15</b>	<b>25.017</b>	<b>25.657</b>	<b>26.297</b>	<b>0.72</b>	<b>4.28</b>	41	2.815	2.861	2.908	3	<b>2</b>
-14	23.908	24.509	25.11	0.75	<b>4.25</b>	42	2.722	2.768	2.814	3.04	<b>1.96</b>
-13	22.857	23.421	23.985	0.78	<b>4.22</b>	43	2.633	2.678	2.724	3.08	<b>1.92</b>
-12	21.859	22.389	22.918	0.81	<b>4.19</b>	44	2.547	2.592	2.637	3.12	<b>1.88</b>
-11	20.912	21.409	21.907	0.84	<b>4.16</b>	45	2.464	2.509	2.553	3.16	<b>1.84</b>
-10	20.013	20.48	20.917	0.87	<b>4.13</b>	46	2.385	2.429	2.473	3.2	<b>1.8</b>
-9	19.116	19.584	20.023	0.9	<b>4.1</b>	47	2.308	2.352	2.395	3.23	<b>1.77</b>
-8	18.322	18.734	19.146	0.93	<b>4.07</b>	48	2.235	2.278	2.231	3.27	<b>1.73</b>
-7	17.54	17.927	18.314	0.97	<b>4.03</b>	49	2.164	2.207	2.249	3.3	<b>1.7</b>
-6	16.797	17.16	17.524	1	<b>4</b>	50	2.096	2.138	2.18	3.34	<b>1.66</b>
-5	16.09	16.431	16.733	1.04	<b>3.96</b>	51	2.03	2.071	2.112	3.37	<b>1.63</b>
-4	15.418	15.739	16.06	1.07	<b>3.93</b>	52	1.966	2.006	2.047	3.41	<b>1.59</b>
-3	14.779	15.08	15.382	1.11	<b>3.89</b>	53	1.904	1.944	1.984	3.44	<b>1.54</b>
-2	14.17	14.454	14.737	1.15	<b>3.85</b>	54	1.844	1.884	1.923	3.48	<b>1.52</b>
-1	13.591	13.857	14.124	1.18	<b>3.82</b>	55	1.787	1.826	1.865	3.51	<b>1.49</b>
<b>0</b>	<b>13.04</b>	<b>13.29</b>	<b>13.54</b>	<b>1.22</b>	<b>3.78</b>	56	1.732	1.77	1.809	3.54	<b>1.46</b>
1	12.505	12.739	12.974	1.26	<b>3.74</b>	57	1.679	1.717	1.754	3.57	<b>1.43</b>
2	11.995	12.215	12.436	1.3	<b>3.7</b>	58	1.628	1.665	1.702	3.6	<b>1.4</b>
3	11.509	11.717	11.924	1.34	<b>3.66</b>	59	1.579	1.615	1.652	3.63	<b>1.37</b>

4	11.047	11.241	11.436	1.38	<b>3.62</b>	60	1.531	1.567	1.603	3.66	<b>1.34</b>
5	10.606	10.789	10.971	1.42	<b>3.58</b>	61	1.485	1.521	1.556	3.69	<b>1.31</b>
6	10.186	10.357	10.529	1.47	<b>3.53</b>	62	1.441	1.476	1.511	3.72	<b>1.28</b>
7	9.785	9.945	10.107	1.51	<b>3.49</b>	63	1.399	1.433	1.467	3.75	<b>1.25</b>
8	9.403	9.554	9.705	1.55	<b>3.45</b>	64	1.357	1.391	1.425	3.78	<b>1.22</b>
9	9.038	9.18	9.322	1.59	<b>3.41</b>	<b>65</b>	<b>1.318</b>	<b>1.351</b>	<b>1.384</b>	<b>3.8</b>	<b>1.2</b>
10	8.69	8.823	8.956	1.64	<b>3.36</b>	66	1.279	1.312	1.344	3.83	<b>1.17</b>
11	8.357	8.482	8.607	1.68	<b>3.32</b>	67	1.242	1.274	1.306	3.86	<b>1.14</b>
12	8.04	8.157	8.274	1.73	<b>3.27</b>	68	1.206	1.237	1.269	3.88	<b>1.12</b>
13	7.736	7.816	7.957	1.77	<b>3.23</b>	69	1.171	1.202	1.233	3.91	<b>1.09</b>
14	7.446	7.55	7.653	1.81	<b>3.19</b>	70	1.137	1.168	1.199	3.93	<b>1.07</b>
15	7.169	7.266	7.363	1.86	<b>3.14</b>	71	1.105	1.135	1.165	3.96	<b>1.04</b>
16	6.9	6.991	7.082	1.9	<b>3.1</b>	72	1.074	1.103	1.133	3.98	<b>1.02</b>
17	6.644	6.729	6.814	1.95	<b>3.05</b>	73	1.043	1.072	1.101	4	<b>1</b>
<b>18</b>	<b>6.398</b>	<b>6.478</b>	<b>6.558</b>	<b>1.99</b>	<b>3.01</b>	74	1.014	1.043	1.071	4.02	<b>0.98</b>
19	6.163	6.238	6.313	2.04	<b>2.96</b>	75	0.986	1.014	1.042	4.05	<b>0.95</b>
20	5.938	6.008	6.078	2.09	<b>2.91</b>	76	0.959	0.986	1.014	4.07	<b>0.93</b>
21	5.723	5.789	5.854	2.13	<b>2.87</b>	77	0.932	0.959	0.986	4.09	<b>0.91</b>
22	5.517	5.578	5.64	2.18	<b>2.82</b>	78	0.907	0.933	0.96	4.11	<b>0.89</b>
23	5.32	5.377	5.484	2.22	<b>2.78</b>	79	0.882	0.908	0.934	4.13	<b>0.87</b>
24	5.131	5.185	5.238	2.27	<b>2.73</b>	80	0.858	0.884	0.91	4.15	<b>0.85</b>
25	4.95	5	5.05	2.31	<b>2.69</b>	<b>3274 type sensor resistance table</b>					

❖ Discharged temperature sensor (50K)

T (°C)	R-min (KΩ)	R-nom (KΩ)	R-max (KΩ)	T (°C)	R-min (KΩ)	R-nom (KΩ)	R-max (KΩ)
0	157.7	161.2	164.7	56	14.16	14.48	14.81
1	150.2	153.4	156.7	57	13.65	13.96	14.28
2	142.9	145.9	148.9	58	13.15	13.46	13.77
3	136.1	138.9	141.7	59	12.69	12.99	13.30
4	129.7	132.3	134.9	60	12.23	12.53	12.83
5	123.6	126.0	128.4	61	11.80	12.09	12.39
6	117.8	120.0	122.3	62	11.39	11.67	11.96
7	112.2	114.3	116.4	63	10.98	11.26	11.54
8	107.1	109.0	111.0	64	10.60	10.87	11.15
9	102.1	103.9	105.7	65	10.23	10.50	10.77
10	97.42	99.08	100.8	66	9.880	10.14	10.41
11	92.97	94.51	96.06	67	9.537	9.792	10.05
12	88.74	90.17	91.61	68	9.211	9.460	9.715
13	84.73	86.05	87.38	69	8.897	9.141	9.391
14	80.92	82.14	83.37	70	8.595	8.834	9.078
15	77.29	78.42	79.56	71	8.306	8.539	8.778
16	73.84	74.89	75.95	72	8.028	8.256	8.490
17	70.57	71.54	72.51	73	7.759	7.983	8.212
18	67.46	68.35	69.25	74	7.501	7.720	7.944
19	64.49	65.32	66.15	75	7.254	7.468	7.687
20	61.68	62.44	63.20	76	7.016	7.225	7.440
21	59.00	59.70	60.40	77	6.786	6.991	7.201
22	56.44	57.09	57.74	78	6.565	6.765	6.971
23	54.02	54.61	55.20	79	6.352	6.548	6.749
24	51.70	52.25	52.80	80	6.147	6.339	6.536
25	49.50	50.00	50.50	81	5.950	6.138	6.331
26	47.37	47.87	48.37	82	5.761	5.944	6.133
27	45.34	45.84	46.34	83	5.578	5.757	5.942
28	43.41	43.91	44.41	84	5.401	5.577	5.758
29	41.59	42.08	42.57	85	5.231	5.403	5.580
30	39.84	40.33	40.82	86	5.069	5.237	5.410
31	38.18	38.66	39.15	87	4.912	5.076	5.245
32	36.59	37.07	37.55	88	4.760	4.921	5.087
33	35.07	35.55	36.03	89	4.615	4.772	4.934
34	33.64	34.11	34.58	90	4.474	4.628	4.787
35	32.27	32.73	33.20	91	4.338	4.489	4.645
36	30.95	31.41	31.87	92	4.207	4.354	4.506
37	29.70	30.15	30.61	93	4.081	4.225	4.374
38	28.50	28.95	29.40	94	3.958	4.099	4.245
39	27.37	27.81	28.25	95	3.840	3.978	4.121
40	26.29	26.72	27.16	96	3.726	3.861	4.001
41	25.24	25.67	26.10	97	3.616	3.748	3.885
42	24.25	24.67	25.09	98	3.509	3.639	3.773
43	23.31	23.72	24.14	99	3.407	3.534	3.665
44	22.41	22.81	23.22	100	3.308	3.432	3.560
45	21.53	21.93	22.33	101	3.212	3.333	3.459
46	20.71	21.10	21.50	102	3.119	3.238	3.361
47	19.92	20.30	20.69	103	3.030	3.146	3.267
48	19.16	19.54	19.92	104	2.942	3.056	3.174
49	18.44	18.81	19.18	105	2.858	2.970	3.086
50	17.75	18.11	18.48	106	2.778	2.887	3.000
51	17.08	17.44	17.80	107	2.699	2.806	2.917
52	16.44	16.79	17.14	108	2.623	2.728	2.837

53	15.84	16.18	16.53	109	2.549	2.652	2.758
54	15.26	15.59	15.93	110	2.479	2.579	2.683
55	14.69	15.02	15.35				

## Annex II

### Version information

Version	Editor	Time	Revised information
	Serhii	2023/09/25	Second edition